

### C34 Classic<sup>™</sup> Direct Vent Freestanding Gas Stove

## Owners & Installation Manual





C34 Video

www.regency-fire.com

MODELS: C34-NG11 Natural Gas C34-LP11 Propane

#### **A** WARNING

#### FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury, death, or property damage.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- WHAT TO DO IF YOU SMELL GAS
  - Do not try to light any appliance.
  - Do not touch any electrical switch: do not use any phone in your building. Leave the building immediately.
  - Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.
  - If you cannot reach your gas supplier, call the fire department.
  - Installation and service must be performed by a qualified installer, service agency or the gas supplier.

Tested by:

Intertek

Certified to/Certifié pour: ANSI Z21.88-2019

Installer: Please complete the details on the back cover and leave this manual with the homeowner.

Homeowner: Please keep these instructions for future reference.

## **REGENCY Classic Direct Vent Freestanding Gas Stove**

#### To the New Owner:

Congratulations! You are the owner of a state-of-the-art Gas Stove by Fireplace Products International Ltd. The Regency® Gas Series of hand-crafted appliances has been designed to provide you with all the warmth and charm of a woodstove, at the flick of a switch. The models C34-NG11 and C34-LP11 of this series have been approved by Intertek for both safety and efficiency. As it also bears our own mark, it promises to provide you with economy, comfort and security for many trouble-free years to follow. Please take a moment now to acquaint yourself with these instructions and the many features of your CLASSIC Direct Vent Freestanding Gas Stove.



A barrier designed to reduce the risk of burns from the hot viewing glass is provided with this appliance and must be installed for the protection of children and other at risk individuals.

#### CAUTION:

HOT WHILE IN OPERATION. DO NOT TOUCH. SEVERE BURNS MAY RESULT. KEEP CHILDREN, CLOTHING, FURNITURE, GASOLINE, AND ANY OTHER LIQUIDS WITH FLAMMABLE VAPOURS AWAY.

KEEP BURNER AND CONTROL COMPARTMENT CLEAN.
SEE INSTALLATION AND OPERATING INSTRUCTIONS ACCOMPANYING APPLIANCE.

20-408



We recommend that our products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) or in Canada by Wood Energy Technical Training (WETT).

#### INFORMATION FOR MOBILE/MANUFACTURED HOMES AFTER FIRST SALE

This Regency® product has been tested and listed by Intertek as a Direct Vent Room Heater to the following standards: ANSI Z21.88.

This Direct Vent System Appliance must be installed in accordance with the manufacturer's installation instructions and the Manufactured Home Construction and Safety Standard, Title 24 CFR, Part 3280, or the current Standard of Fire Safety Criteria for Manufactured Home Installations, Sites, and Communities ANSI/NFPA 501A, and with CAN/CSA Z240-MH Mobile Home Standard in Canada.

This appliance installation must comply with the manufacturer's installation instructions and local codes, if any. In the absence of local codes follow the current National Fuel Gas Code, ANSI Z223.1 and the current National Electrical Code ANSI/NFPA 70 in the U.S.A., and the current CSA B149.1 Gas Installation Code and the current Canadian Electrical Code CSA C22.1 in Canada.


This Regency® Mobile/Manufactured Home Listed appliance comes factory equipped with a means to secure the unit.


This Regency® Mobile/Manufactured Home listed appliance comes equipped with a dedicated #8 ground lug to which an 8 gauge copper wire from the steel chassis ground must be attached.




C34 Video

### 4 dimensions







ALL PICTURES / DIAGRAMS SHOWN THROUGHOUT THIS MANUAL ARE FOR ILLUSTRATION PURPOSES ONLY. ACTUAL PRODUCT MAY VARY DUE TO PRODUCT ENHANCEMENTS.


Copy of Safety Decal	6
Gas installation Checklist	
For Your Safety	
Important Message	11
Specifications	11
General Safety Information	11
Installation Checklist	12
Locating Your Gas Stove	
Manufactured Mobile Home Additional Requirements	12
Combustion and Ventilation Air	
Clearances to Combustibles	
Lighting Procedure	13
Proflame I Remote Control Operating Instructions	
Proflame I Remote Receiver Battery Replacement	
Optional Fan Installation	
Pedestal Assembly	
Leg and Bottom Shield Assembly	
Venting Introduction	
Installation Precautions	
Safety Precautions for the Installer	
Vent Restrictor Position	
Exterior Vent Terminal Locations	
4" x 6-5/8" Rigid Pipe Cross Reference Chart	
Rigid Pipe Venting Systems	
Venting Arrangements	
Venting Arrangements	
DV Stove Horizontal Vent Kit	
DV Stove Horizontal Vent Kit Installation	
Dura-Vent Termination Kit	
Vertical Termination	
Cathedral Ceilings	
Converting Class-A Metal Chimney to Direct Vent System . System Data	
Gas Connection	
High Elevation	
THIGHT LICEAUTOHITTEE	J/

Gas Pipe Pressure Testing       37         Door installation       39         Log Installation       41         Door and Glass Frame       41         Safety Screen Installation / Removal       42         Remote Control Installation       42         Optional Wall Thermostat       42         Final Check       42         Wiring Diagram       43         Pilot Adjustment       44         Aeration Adjustment       44         First Fire       45
Operation
Operating Instructions
Maintenance
Maintenance Instructions47General Vent Maintenance47Log Replacement47Glass Gasket48Glass Replacement48Removing Valve Assembly48Installing Valve Assembly48Gas Maintenance49
Parts
Main Assembly50Burner Assembly & Log Set51Base Options52
Warranty
Warranty54
Recycling59

### 6 safety decal

This is a copy of the label that accompanies each CLASSIC Direct Vent Freestanding Gas Stove. We have printed a copy of the contents here for your review. The safety label is located on the back panel.

**NOTE:** Regency<sup>®</sup> units are constantly being improved. Check the label on the unit and if there is a difference, the label on the unit is the correct one.



For the State of Massachusetts, installation and repair must be done by a plumber or gas fitter licensed in the Commonwealth of Massachusetts.

For the State of Massachusetts, flexible connectors shall not exceed 36 inches in length.

For the State of Massachusetts, the appliances individual manual shutoff must be a t-handle type valve.

The State of Massachusetts requires the installation of a carbon monoxide alarm in accordance with NFPA 720 and a CO alarm with battery backup in the same room where the gas appliance is installed.

#### MA Code - CO Detector (for the State of Massachusetts only)

#### 5.08: Modifications to NFPA-54, Chapter 10

- (2) Revise 10.8.3 by adding the following additional requirements:
- (a) For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:
- 1. INSTALLATION OF CARBON MONOXIDE DETECTORS. At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gasfitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gasfitter shal observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors
- a. In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.
- b. In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.
- 2. APPROVED CARBON MONOXIDE DETECTORS. Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.
- 3. SIGNAGE. A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".
- 4. INSPECTION. The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a)1 through 4.
- (b) EXEMPTIONS: The following equipment is exempt from 248 CMR 5.08(2)(a)1 through 4:
- 1. The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board; and
- 2. Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.
- (c) MANUFACTURER REQUIREMENTS GAS EQUIPMENT VENTING SYSTEM PROVIDED. When the manufacturer of Product Approved side wall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:
- 1. Detailed instructions for the installation of the venting system design or the venting system components; and
- 2. A complete parts list for the venting system design or venting system.
- (d) MANUFACTURER REQUIREMENTS GAS EQUIPMENT VENTING SYSTEM NOT PROVIDED. When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems", the following requirements shall be satisfied by the manufacturer:
- 1. The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and
- 2. The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.
- (e) A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design instructions shall remain with the appliance or equipmentat the completion of the installation.

### dimensions

#### **GAS INSTALLATION CHECKLIST**

This general checklist does not contain all pertinent installation details or specifics and does not supersede the guidelines in this manual. Your Regency dealer/installer should use it in conjunction with manual instructions. Please follow all local codes and jurisdictions in authority.

Customer:	Date Installed:		
Install Address:	Location of Fireplace:		
Serial No:	Installer:		
Model No:			
Site Requirements		YES	NO
If applicable, are the insulation, vapour barrier, and drywall present	if installed on an outside wall or chase?		
Does the area have a solid continuous base to support the unit?			
Will the area accommodate the size of the applliance and all cleara	nces?		
Are the gas and electrical roughed into the area where the unit is b	eing installed?		
In City & Grandview series cool wall applications, is the chase enclor from the unit must exit via the mandatory ventilation openings.	osure sealed to prevent heat from escaping? All hot air		
In City & Grandview applications, Is the chase enclosure vented wit for details.	th the mandatory heat ventilation openings? See manual		
If applicable, is the masonry/factory built freplace in its original cor	dition with no modifications?		
If applicable, have the hearth requirements been met?			
Unit Setup		YES	NO
If applicable, are the standoffs and top nailing flange extensions in material? See manual for details.	stalled and at the correct depth to accommodate finishing		
If applicable, is the fireplace level and secured, meeting framing cle	earances? See manual for details.		
If applicable, is the unit converted to top or rear vent per manual in	nstructions, and the insulation discarded?		
Venting		YES	NO
Are the venting components approved for the unit installed?			
Does the venting configuration comply with venting diagrams?			
Is venting installed and secured, and are clearances for the vent pi	pe and termination cap maintained?		
If applicable, was a 1/4" rise maintained for every foot of horizonta	l run?		
Was the termination installed and sealed?			
Is the direct vent termination at the highest point in the vent assen	nbly?		
If applicable, are both chimney liners continuous from flue collars to	o termination?		
Electrical and Wiring		YES	NO
Is the appliance connected to the household's 110/120v per local c	odes? Check local codes for receptacle placement.		
Were the connections in the fireplace tested with a circuit tester?			
Is the appliance properly grounded?			
If applicable, is the supplied electrical/gang box affixed to the wall	to facilitate the mounting of the receiver/battery box ?		
If applicable, is all electrical, Ethernet, HDMI, networking, optical, w work as wires/cables of any kind cannot be exposed directly above			
Gas		YES	NO
Does the supply pressure meet the requirements shown on the rati	ng plate?		
Was a conversion performed?			
Was a leak check performed and manifold pressures verified?			

Is the shut-off valve installed and easily accessible to the customer?		
Finishing	YES	NO
If applicable, is only noncombustible material installed in the noncombustible areas?		
Do clearances meet installation and manual requirements?		
Do the mantels and/or projections comply with the installation manual?		
If applicable, was the solid fuel fireplace warning plate installed?		
Is the chase enclosure fully open the full width, height and depth above the fireplace as per the requirements noted in the framing section?		
Appliance Media Setup	YES	NO
Do commands from the remote or wall switch light the pilot and main burner?		
Are the burner media/log set, glass door, and screen installed per instructions in the manual?		
Was the air shutter on the proper setting after running the unit for 20 minutes?		
If applicable, were the surround and trims installed according to the manual?		
Was the operation of the fan, lights (if installed), and flame modulation checked?		
Customer Tutorial and Presentation	YES	NO
Is the customer confident operating the new gas appliance and aware of all the features on the remote?		
Confirm that the rating and lighting plates are attached to the appliance. Do not remove.		
Was the customer informed of the location of the rating and lighting plates?		
Was accessing unit controls in a power outage explained to the customer?		
Are the model and serial numbers and the date of installation of the unit written in the manual and on the checklist?		
Were the warranty and unit registration reviewed with the customer?		
Comments:		

#### FOR YOUR SAFETY

This appliance requires air for proper combustion. Always provide adequate combustion and ventilation air. Follow instructions and information in CSA B149.1 (in Canada) or the National Fuel Gas Code ANS Z223.1/NFPA (in the USA), regarding requirements for combustion and ventilation air.

INSTALLATION AND REPAIR SHOULD BE DONE BY AN AUTHORIZED SERVICE PERSON. THE APPLIANCE SHOULD BE INSPECTED BEFORE USE AND AT LEAST ANNUALLY BY A PROFESSIONAL SERVICE PERSON. MORE FREQUENT CLEANING MAY BE REQUIRED DUE TO EXCESSIVE LINT FROM CARPETING, BEDDING MATERIAL, ETC. IT IS IMPERATIVE THAT CONTROL COMPARTMENTS, BURNERS AND CIRCULATING AIR PASSAGEWAYS OF THE APPLIANCE BE KEPT CLEAN.

DUE TO HIGH TEMPERATURES, THE APPLIANCE SHOULD BE LOCATED OUT OF TRAFFIC AND AWAY FROM FURNITURE AND DRAPERIES.

WARNING: FAILURE TO INSTALL THIS APPLIANCE CORRECTLY WILL VOID YOUR WARRANTY AND MAY CAUSE A SERIOUS HOUSE FIRE.

CHILDREN AND ADULTS SHOULD BE ALERTED TO THE HAZARDS OF HIGH SURFACE TEMPERATURES, ESPECIALLY THE FIREPLACE GLASS, AND SHOULD STAY AWAY TO AVOID BURNS OR CLOTHING IGNITION.

YOUNG CHILDREN SHOULD BE CAREFULLY SUPERVISED WHEN THEY ARE IN THE SAME AREA AS THE APPLIANCE. TODDLERS, YOUNG CHILDREN AND OTHERS MAY BE SUSCEPTIBLE TO ACCIDENTAL CONTACT BURNS. A PHYSICAL BARRIERS IS RECOMMENDED IF THERE ARE AT RISK INDIVIDUAL IN THE HOUSE. TO RESTRICT ACCESS TO A FIREPLACE OR STOVE, INSTALL AN ADJUSTABLE SAFETY GATE TO KEEP TODDLERS, YOUNG CHILDREN AND OTHER AT RISK INDIVIDUALS OUT OF THE ROOM AND AWAY FROM HOT SURFACES.

CLOTHING OR OTHER FLAMMABLE MATERIAL SHOULD NOT BE PLACED ON OR NEAR THE APPLIANCE.

A BARRIER DESIGNED TO REDUCE THE RISK OF BURNS FROM THE HOT VIEWING GLASS IS PROVIDED WITH THIS APPLIANCE AND SHALL BE INSTALLED FOR THE PROTECTION OF CHILDREN AND OTHER AT-RISK INDIVIDUALS.

ANY SAFETY SCREEN, GUARD, OR BARRIER REMOVED FOR SERVICING THE APPLIANCE, MUST BE REPLACED PRIOR TO OPERATING THE APPLIANCE.

IFTHEBARRIER BECOMES DAMAGED, THE BARRIER SHALL BE REPLACED WITH THE MANUFACTURER'S BARRIER FOR THIS APPLIANCE.



## IMPORTANT MESSAGE SAVE THESE INSTRUCTIONS

The CLASSIC Direct Vent Freestanding Gas Stove must be installed in accordance with these instructions. Carefully read all the instructions in this manual first. Consult the building authority having jurisdiction to determine the need for a permit prior to starting the installation.

#### - WARNING -

Failure to follow the instructions could cause a malfunction of the heater which could result in death, serious bodily injury, and/or property damage. Failure to follow these instructions may also void your fire insurance and/or warranty.

Note: These instructions take precedence over Simpson Dura-Vent instructions

#### **SPECIFICATIONS**

**Fuels:** C34-NG11 is approved for use with natural gas. C34-LP11 is approved for use with

liquefied petroleum gases (propane).

**Electrical:** 120V. A.C. system.

Optional circulation fan: 125/75 CFM.

**Log Sets:** Ceramic fibre, 4 per set.

Vent System: Coaxial (65/8" outer/4" inner liner)

rigid flue and termination cap.

SHOULD OVERHEATING OCCUR, OR THE GAS SUPPLY FAIL TO SHUT OFF, SHUT OFF THE MANUAL GAS VALVE TO THE APPLIANCE BEFORE SHUTTING OFF THE ELECTRICAL SUPPLY.

#### - WARNING -

Risk of fire or electric shock. Only qualified service personnel shall be used to install and provide maintenance of this appliance.

WARNING: Cancer and Reproductive Harm www.P65Warnings.ca.gov

- Provide adequate clearances for servicing, proper operation and around the air openings into the combustion chamber.
- The appliance may be installed on a flat, solid, continuous surface (e.g. wood, metal, concrete).
   This may be the floor, or it can be raised up on a platform to enhance its visual impact. If the appliance is going to be installed on carpeting, see clearances to combustibles in "Clearances to Combustibles" section.

The CLASSIC Direct Vent Freestanding Gas Stove can be installed in a wide variety of ways and will fit nearly any room layout. It may be installed in a recessed position, framed out into the room, or across a corner. This appliance is Listed for Alcove installations, maintain minimum Alcove clearances as follows, minimum ceiling height of 65-11/16", minimum width of 48" and a maximum depth of 36".

- 3. The CLASSIC Direct Vent Freestanding Gas Stove is approved for alcove installations, which meet the clearances listed in "Clearances to Combustibles" section. This unit can be installed in a bedroom, when installed with a millivolt thermostat. This unit is approved for manufactured home installations, see "Venting Arrangements" section for the required vent arrangements. If installed into a manufactured or mobile home the unit must be bolted down to the floor.
- 4. We recommend that you plan your installation on paper using exact measurements for clearances and floor protection before actually installing this appliance. Have a qualified building inspector review your plans before installation.

#### **GENERAL SAFETY INFORMATION**

- The appliance installation must conform with local codes or, in the absence of local codes, with the current Canadian or National Electrical Codes, CSA B149.1 or ANSI Z223.1 Installation Codes.
- The appliance when installed, must be electrically grounded in accordance with local codes, or in the absence of local codes with the current National Electrical Code, ANSI/NFPA 70 or CSA C22.1 Canadian Electrical Code.
- The appliance should be inspected for shipping damage before use and serviced annually by a professional service person. More frequent cleaning may be required due to excessive lint from carpeting, bedding material, etc. It is imperative that control compartments, and circulating air passageways of the appliance be kept clean.
- See general construction and assembly instructions. The appliance and vent should be enclosed when installed in or passing through a living area.
- 5. This appliance must be connected to the specified vent and termination cap to the outside of the building envelope.
- Never vent to another room or inside a building.
   Make sure that the vent is fitted as per the instructions starting in "Venting Introduction" section.
- 7. Inspect the venting system annually for blockage and any signs of deterioration.
- 8. Venting terminals shall not be recessed into a wall or siding.
- 9. Any safety glass removed for servicing must be replaced prior to operating the appliance.
- 10 To prevent injury, do not allow anyone who is unfamiliar with the operation to use the fireplace.

## INSTALLATION CHECKLIST

- Locate your appliance. Refer to the following sections:
  - a. Locating Your Classic Gas Stove
  - b. Clearances to Combustibles
  - venting. See "Exterior Vent Terminal Locations" to " Venting Arrangements" sections.
- 2. Install Optional Fan. Refer to "Optional Fan Installation" section.
- Assemble stove base pedestal or bottom shield and legs. Refer to "Pedestal Assembly" or "Leg and Bottom Shield Assembly" sections.
- 4. Choose a venting option and Install accordingly. Refer to the following sections where applicable:
  - a. DV Stove Horizontal Vent Kit
  - b. Dura-Vent Termination kits
  - c. Vent Restrictor setting
  - d. Converting Class-A Metal Chimney or Masonry Chimney to Direct Vent System.
- Make gas and electrical connections. Refer to "Gas Connection" section. Test the pilot. Must be as per Diagram in "Pilot Adjustment" section.
- Install 4-AA batteries into receiver. This will enable operation of appliance manually when in "ON" position.

Note: If optional fan is not purchased, Batteries are required in both remote receiver (4  $\times$  AA Batteries) & remote hand held ( 3  $\times$  AAA batteries) in order to operate appliance using the remote control.

- Test gas pressure. Refer to "Gas Pipe Pressure Testing" section.
- 8. Install standard and optional features. Refer to the following sections where applicable:
  - a. Log Installation
  - b. Door and Glass Frame
  - c. Door Handle
  - d. Safety Screen
  - e. Remote Control
  - f. Wall Thermostat
  - g. Install 1 AA battery into DC spark box (See instructions in manual)
  - h. Fan Kit
- 9. Final check. Refer to "Final Check" section.

Before leaving this unit with the customer, the installer must ensure that the appliance is firing correctly and operation fully explained to customer.


#### This includes:

- Clocking the appliance to ensure the correct firing rate (rate noted on label) after burning appliance for 15 minutes.
- If required, adjusting the primary air to ensure that the flame does not carbon. First allow the unit to burn for 15-20 min. to stabilize.
- 3. Check for proper draft.

**CAUTION:** Any alteration to the product that causes sooting or carboning that results in damage is not the responsibility of the manufacturer.

## LOCATING YOUR GAS STOVE

When selecting a location for your stove, ensure that the clearances on this page are met as well as ensuring that there is adequate accessibility for servicing and proper operation.



- A) Cross Corner
- B) Room Divider
- C) Island
- D) Flat on Wall
- E) Flat on Wall Corner
- F) Flush with Wall/Alcove

For Vent Termination requirements, see "Exterior Vent Terminal Locations" section.

## MANUFACTURED MOBILE HOME ADDITIONAL REQUIREMENTS

- 1. Ensure that structural members are not cut or weakened during installation.
- Ensure proper grounding using the #8 ground lug provided. See "Optional Fan Installation" section.
- Appliance must be anchored to the floor. See "Pedestal Assembly" & "Leg and Bottom" sections.

## COMBUSTION AND VENTILATION AIR

The combustion air from this appliance is drawn from outside the building through the outer flue. **Extra provision for combustion air is not required.** 

## CLEARANCES TO COMBUSTIBLES

The clearances listed below are MINIMUM distances. Measure the clearance to both the appliance and the chimney connector. The farthest distance is correct if the two clearances do not coincide. For example, if the appliance is set as indicated in one of the Diagrams but the back is too close, move the stove until the correct clearance to the back is obtained.

This unit can be installed on a solid combustible surface like a wood floor. This unit can also be installed directly on carpeting or vinyl when the bottom pedestal cover plate (provided with the unit) is installed.

This appliance may be installed only with the clearances as shown in the situations pictured. Do not combine clearances from one type of installation with another in order to achieve closer clearances.

Use the minimum clearances shown in the Diagrams below:

## C34 Clearance to Combustibles Side Wall to Unit 10"/ 250 mm Back Wall to Unit 6" / 150 mm


B Back Wall to Unit 6" / 150 mm E Side Wall to Unit 1.5"/ 38 mm

#### **C34 Reference Dimensions**

C Back Wall to Flue Centerline 13" / 330 mm
D Side Wall to Flue Centerline 22"/ 559 mm
F Side Wall to Flue Centerline 14"/ 356 mm

Minimum ceiling height is 36" / 914 mm from top of unit.

Minimum clearance to vent 1-1/4" (32 mm).



#### LIGHTING PROCEDURE

**IMPORTANT:** The remote control system supplied with this appliance has several options for starting/operating the appliance using the power button and ON/OFF key on the hand-held transmitter.

Prior to operating this appliance, <u>please read</u> the remote control operating instructions (packaged with remote control) to understand how to operate this remote control system. Option to download remote functions video with QR code below.



Proflame video

Ensure the wall switch/receiver is in the remote position (see Diagram 1).
 Set Switch to
 Remote





Diagram 1

Press and release the ON/OFF button on the remote handheld transmitter (see Diagram 2). An audible beep should be heard from the receiver.



Diagram 2 Remote shown in Manual Mode on Hi



- **3.** After approximately 4 seconds the spark ignition system will spark for 60 seconds to light the pilot.
- 4. The unit will turn on.


**Note:** The first try for ignition will last approximately 60 seconds. If there is no flame ignition (rectification) the board will stop sparking for approximately 35 seconds. After wait time, the board will start second try for ignition by sparking for approximately 60 seconds. If there is still no positive ignition the board will go into lock out.

The system will need to be reset as follows:

- a) Turn the system off using ON/OFF switch or press ON/OFF button if using remote.
- **b)** After approximately 2 seconds turn on ON/OFF switch or press ON/OFF button if using remote.
- c) Repeat step 2.

#### SHUTDOWN PROCEDURE

- 1. Turn the wall-mounted switch or remote to the "OFF" position.
- 2. Press "OFF" on the remote control.
- 3. Turn the gas control knob to the "OFF" position to turn off the pilot.



#### PROFLAME I REMOTE CONTROL OPERATING INSTRUCTIONS

**IMPORTANT:** The Proflame Transmitter 2 is an integrated part of the Proflame 2 System, which consists of these elements:

- Proflame 2 Transmitter, to be used in conjunction with:
- Integrated Fireplaces Control (Proflame 2 IFC)

The Proflame 2 Transmitter provides for controlling the following hearth appliance functions:

- Main Burner On/Off
- 2. Main Burner flame modulation (6 levels)
- 3. Choice of standing or intermittent pilot (CPI/IPI)
- 4. Thermostat and Smart thermostat functions
- 5. Accent light modulation (6 levels)\*\*
- 6. Split flow valve\*\*
- 7. Comfort Fan speed modulation (6 levels)\*\*
- \*\* This feature is not available on all models.

The Proflame Transmitter uses a streamline design with a simple button layout and informative LCD display (Fig. 1). A Mode Key is provided to index between the features and a Thermostat Key is used to turn on/off or index through Thermostat functions (Fig. 1 & 2). Additionally, a Key Lock feature is provided (Fig. 22).



Figure 1: Proflame Transmitter




Figure 2: Transmitter LCD Display

Note: May not be exactly as shown as hand-held may be silver or black.

TECHNICAL DATA REMOTE CONTROL					
Supply Voltage	4.5V (three 1.5V AAA batteries)				
Ambient temperature ratings	0 - 50°C (32 - 122°F)				
Radio Frequency	315 MHZ				

## WARNING: THE TRANSMITTER AND RECEIVER ARE RADIO FREQUENCY DEVICES. PLACING THE RECEIVER IN OR NEAR METAL MAY SEVERELY REDUCE THE SIGNAL

#### **ATTENTION!**

- Turn "OFF" the main gas supply of the appliance during installation or maintenance of the Receiver device.
- Turn "OFF" main gas supply to the appliance prior to removing or reinserting the batteries.
- In case of remote control malfunction, turn off the IFC device using the "ON/OFF" main switch.
- For installation / maintenance, switch off the IFC device removing main power supply plug.

#### **OPERATING PROCEDURE**

#### Pairing the remote control to remote receiver/ battery holder (if required)

Power the receiver. Press the "PRG" button located on the top right hand side of receiver, see the receiver instruction (\*). The Receiver will "beep" three (3) times to indicate that it is ready to synchronize with a Transmitter. Install the 3 AAA type batteries in the Transmitter battery bay, located on the base of the Transmitter. (fig. 3) With the batteries already installed in the Transmitter, push the On button. The Receiver will "beep" four times to indicate the Transmitter's command is accepted and sets to the particular code of that Transmitter. The system is now initialized.

(\*) The receiver may be independent or integral to the IFC hearth appliance control module. The receiver instruction may not be independent when part of the IFC.

**Note:** Only use regular alkaline batteries. Do not use rechargeable or lithium batteries.



Figure 3: Battery Compartment

#### **Temperature indication Display**

With the system in the "OFF" position, press the Thermostat Key and the Mode Key at the same time. Look at the LCD screen on the transmitter to verify that a C or F is visible to the right of the room temperature display (Figures 4 & 5).






Figure 4: Remote Control display in Fahrenheit.

Figure 5: Remote Control display in Celsius.

#### **Turn on the Appliance**

With the system OFF, press the ON/ OFF Key on the Transmitter. The Transmitter display will show some other active Icons on the screen. At the same time the Receiver will activate the appliance. A single "beep" from the Receiver will confirm reception of the command.





Figure 6: Remote Control display


#### **Turn off the Appliance**

With the system ON, press the ON/OFF Key on the Transmitter. The Transmitter LCD display will only show the room temperature (Fig. 6). At the same time the Receiver will turn off the appliance. A single "beep" from the Receiver confirms reception of the command.

#### **Remote-Flame Control**

The Proflame has six (6) flame levels. With the system on, and the flame level at the maximum in the appliance, pressing the Down Arrow Key once will reduce the flame height by one step until the flame is turned off. The Up Arrow Key will increase the flame height each time it is pressed. If the Up Arrow Key is pressed while the system is on but the flame is off, the flame will come on in the high position (Fig. 7 & 8). A single "beep" will confirm reception of the command.





6 on 75 f



Fig. 8 Flame level 5

#### **Room Thermostat (Transmitter Operation)**

The Remote Control can operate as a room thermostat. The thermostat can be set to a desired temperature to control the comfort level in a room. To activate this function, press the Thermostat Key (Fig. 1). The LCD display on the Transmitter will change to show that the room thermostat is "ON" and the set temperature is now displayed (Fig. 9). To adjust the set temperature, press the Up or Down Arrow Keys until the desired set temperature is displayed on the LCD screen of the Transmitter.




Figure 9 Figure 10

#### **Smart Thermostat (Transmitter Operation)**

The Smart Thermostat function adjusts the flame height in accordance to the difference between the set point temperature and the actual room temperatures. As the room temperature gets closer to the set point the Smart Function will modulate the flame down.

To activate this function, press the Thermostat Key (Fig. 1) until the word "SMART" appears to the right of the temperature bulb graphic (Fig. 11). To adjust the set temperature, press the Up or Down Arrow Keys until the desired set temperature is displayed on the LCD screen of the Transmitter (Fig. 12).

Note. When Smart Thermostat is activated, manual flame height adjustment is disabled.






Figure 11: Smart Flame Function

Figure 12

#### Fan Speed Control\*\*

If the appliance is equipped with a hot air circulating fan, the speed of the fan can be controlled by the Proflame system. The fan speed can be adjusted through six (6) speeds. To activate this function use the Mode Key (fig.1) to index to the fan control icon (Fig. 13). Use the Up/Down Arrow Keys (fig.1) to turn on, off or adjust the fan speed (fig. 14). A single "beep" will confirm reception of the command.






Figure 14

#### Remote dimmer control (Light)\*\*

The auxiliary function controls the AUX power outlet by the dimmable light control. To activate this function use the Mode Key (fig. 1) to index to the AUX icon (fig. 15 & 16).

The intensity of the output can be adjusted through six (6) levels. Use the Up/Down Arrow Keys (fig.1) adjust the output level (fig. 16). A single "beep" will confirm reception of the command.

Note: This function is available only with the IFC Control Module.






Figure 15


Figure 16

#### **KEY LOCK**

Figure 18

This function will lock the keys to avoid unsupervised operation. To activate this function, press the MODE and UP Keys at the same time (fig. 21).

To de-activate this function, press the MODE and UP Keys at the same time.



#### LOW BATTERY POWER DETECTION

#### **Transmitter**

The life span of the remote control batteries depends on various factors: quality of the batteries used, the number of ignitions of the appliance, the number of changes to the room thermostat set point, etc. When the Transmitter batteries are low, a Battery Icon will appear on the LCD display of the Transmitter (Fig. 22) before all battery power is lost. When the batteries are replaced this Icon will disappear.




Figure 19

**ENABLE / DISABLE** functions on the Proflame I remote only.

- 1. Remove one battery from the remote.
- 2. Press and hold both the **ON/OFF** and the **MODE** button at the same time
- Reinstall the battery (removed in Step 1) while still holding both buttons (keep holding both buttons and once all batteries are installed then release the MODE button only).
- 4. The screen will show CFG.
- 5. Use the up or down arrow button to program out the function on the remote.

**Note:** You should never program out the fan (if installed) feature on the remote. It is not possible to remove the thermostat mode on this remote control.

#### PROFLAME I REMOTE RECEIVER BATTERY REPLACEMENT

#### **Remote Receiver Battery Replacement**

How to replace/add the batteries on remote receiver.

Note: If no fan control module is installed (included with the optional fan kit), 4 AA batteries are mandatory in the remote receiver to operate appliance when using remote control.

STEP 1


Move both the left/right slides as shown below.

The battery compartment will be pushed out slightly, to allow to easily extract it


STEP 2

Extract the battery compartment from the remote receiver/battery holder


Replace 4 x AA batteries and insert the battery compartment back into remote receiver/battery holder



STEP 3



Close the right slide



STEP 4 Reinstall wall cover plate with 2 Phillips head screws.

#### **OPTIONAL FAN INSTALLATION**

120 Volt AC power is needed for the fan.

#### **WARNING: Electrical Grounding Instructions**

This appliance is equipped with a three pronged (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. Do not cut or remove the grounding prong from this plug.

**Pedestal unit:** To install the fan in an installed stove-access from front through the pedestal by following the directions below. If the stove is not installed - access through the back - open back as shown below.




Diagram 1 Remove 7 screws on top Loosen 4 screws on bottomslide access panel to the right to remove

**Leg unit:** Loosen 7 screws on bottom access panel–slide panel toward the front to remove.




Diagram 2 Loosen 6 screws-slide access panel to the front of unit to remove

#### **IMPORTANT Disconnect power supply before servicing**




Diagram 3

- Open pedestal door and remove door cover plate by removing 4 screws. See Diagram 3.
- 2. Remove valve cover plate by removing 2 screws.
- 3. Remove wire from receiver.
- **4.** Screw the four screws provided into the nutserts as shown in Diagram 5. Do not tighten screws.
- **5.** Place the fan assembly partially in door cover plate hole. See Diagram 4.
- **6.** Attach the 2 ground wires (green) to the ground lug as per Diagram 4.





Diagram 4


Note: Ground lug is located on the bottom of the fan assembly. See Diagram 4.

- 7. Lift the fan assembly in through the pedestal and up through the cut out as shown in Diagrams 5 and 6.
- **8.** Place the insulation gasket on the back of the fan. Line up the keyhole slots with the matching screws and pull back slightly to lock into place. While holding fan assembly in place, tighten screws.

#### View from back of stove



#### View from back of stove



9. Slide thermodisc under the thermodisc bracket.




Diagram 7

10. Install the FCM (fan control module) to the floor of the pedestal or bottom heat shield with supplied magnets. Connect the FCM power cord to the supplied extension cord and then run extension cord out the back of the unit. See below.





Diagram 8 Use strain relief grommet when running extension cord through Pedestal



Run the extension cord through the largest opening at the back when using the Bottom Heat Shield with Legs option-no strain relief grommet required.

11. Plug in the fan power cord to the Fan Control Module into the outlet marked "Fan". Plug the FCM-COM wire from the remote control wiring harness into the location on the Fan Control Module marked "COM". Turn the switch on the Fan Control Module to the ON position. ON is to the left. The "O" is the off position.








Diagram 10

Caution: Ensure that the wires do not touch any hot surfaces.

Note: The #8 ground lug is a dedicated ground for mobile home use only.

- **12.** Plug 120 volt AC power cord into a nearby receptacle.
- **13.** See the Proflame instructions for coding the remote hand-held to the receiver and for operating instructions.

#### **IMPORTANT:**


THESE FANS COLLECT A LOT OF DUST FROM WITHIN YOUR HOME. ENSURE YOU MAINTAIN THESE FAN MOTORS ON A REGULAR BASIS BY VACUUMING THE FAN BLADES AND THE HOUSING WITH A SOFT BRUSH NOZZLE.

#### **FAN REMOVAL**

- 1. Disconnect the power to the fan.
- 2. Allow the stove to cool to room temperature.
- **3.** Open the pedestal door and remove the screws on the door cover plate. (Leg units: remove the bottom access panel.)
- **4.** Unplug the fan from the FCM.
- **5.** Loosen the screws of the nutserts.
- **6.** Remove the fan assembly from the key slots at the fan base and pull fan out through the rectangular opening. (Diagram 5).
- 7. Turn fan 90 degrees. (Diagram 5). (Pedestal units only).
- **8.** Disconnect the green ground wires to the grounding lug.
- **9** Remove fan from stove. (Diagram 3)

#### PEDESTAL ASSEMBLY

- For easier assembly, tip the stove on its back (preferably onto a soft surface to prevent scratching).
- Unscrew the 4 bolts in the underside of the stove. Align the holes in the corners of the pedestal top with the corresponding holes in the base of the stove. Use washers which are supplied with the pedestal as shown in Diagram. Reinstall bolts.
- 3. Push the Regency® logo into the two holes in the front bottom left corner of the pedestal cover plate.




Note: Any paint touch up should be done prior to placing logo on a pedestal.

#### **LEG AND BOTTOM SHIELD ASSEMBLY**


These instructions apply to the steel leg and painted cast leg. It will be easier to attach the legs to the stove if it is tipped on its back (preferably on a soft surface to prevent scratching).

- 1. Remove the 4 bolts in the underside of the base and discard.
- Slide the bolt and washer (supplied with the bottom shield) through the leg, then slide the bottom shield in between the leg and the base of the stove. Tighten the bolts.
- 3. Level the stove by adjusting the levelling bolts in the bottom of each leg.



C34 leg & bottom shield assy legcls2.eps

Anchoring Brackets Hold Down Package Part# 846-585



#### **VENTING INTRODUCTION**

The DV Stove Horizontal Vent Kit and the Simpson Dura-Vent Direct Vent venting systems, in combination with the Classic Direct Vent Freestanding Gas Stove, C34-NG11 and C34-LP11, have been tested and listed as direct vent heater systems by Intertek.

If converting a Class-A Metal Chimney or Masonry Chimney to a Direct Vent system, see instructions in "Converting Class-A Metal Chimney or Masonry Chimney to Direct Vent System" section.

The C34-11 uses the "balanced flue" technology coaxial system. The inner liner vents products of combustion to the outside while the outer pipe draws outside combustion air into the combustion chamber thereby eliminating the need to use heated room air for combustion and losing warm room air up the chimney.

### Note: These flue pipes must not be connected to any other appliance.

The gas appliance and vent system must be vented directly to the outside of the building, and never be attached to a chimney serving a separate solid fuel or gas burning appliance. Each direct vent gas appliance must use its own separate vent system. Common vent systems are prohibited.

#### **IMPORTANT**

Read all instructions carefully before starting the installation. Failure to follow these instructions may create a fire or other safety hazard, and will void the warranty. Be sure to check the venting and clearance to combustible requirements. Consult your local building codes before beginning installation.

The location of the termination cap must conform to the requirements in the Exterior Vent Terminal Locations Diagram in "Exterior Vent Terminal Locations" section.

## INSTALLATION PRECAUTIONS

These venting systems are engineered products that have been designed and tested for use with the C34-NG11 and the C34-LP11. The warranty will be voided and serious fire, health or other safety hazards may result from any of the following actions:

- Installation of any damaged Direct Vent component
- 2. Unauthorized modification of the Direct Vent System
- **3.** Installation of any component part not manufactured or approved by Simpson Dura-Vent or Fireplace Products International Ltd.
- **4.** Installation other than as instructed by Simpson Dura-Vent and Fireplace Products International Ltd.

Warning: Always maintain required clearances (airspaces) to nearby combustibles to prevent a fire hazard. Do not fill air spaces with insulation.

Be sure to check the vent termination clearance requirements from decks, windows, soffits, gas regulators, air supply inlets and public walkways as specified in the "Exterior Vent Terminal Locations" section and in your local building codes.

The gas appliance and vent system must be vented directly to the outside of the building, and never be attached to a chimney serving a separate solid fuel or gas-burning appliance. Each direct vent gas appliance must use its own separate vent system. Common vent systems are prohibited.


## SAFETY PRECAUTIONS FOR THE INSTALLER


- 1. Wear gloves and safety glasses for protection.
- Exercise extreme caution when using ladders or on roof tops.
- Be aware of electrical wiring locations in walls and ceilings.


## VENT RESTRICTOR POSITION

Vent restriction is required for certain venting installations, see the Diagrams in "Venting Arrangement" section to determine if they are required for your installation.


The vent restrictor has three settings: "C" Center (factory setting), "L" Left, and "R" Right. Simply loosen the screws and push the vent restrictor plate to the correct position. Tighten the screws.







#### **EXTERIOR VENT TERMINAL LOCATIONS**



	Minimum Clearance Requirements	Canada <sup>1</sup>	USA <sup>2</sup>
A	Clearance above grade, veranda, porch, deck, or balcony	12"(30cm)	12"(30cm)
В	Clearance to window or door that may be opened	12"(30cm)	9" (23cm)
С	Clearance to permanently closed window	*	*
D	Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61cm) from the center line of the terminal (check with the local code)	18"(46cm)	18"(46cm)
E	Clearance to unventilated soffit	12"(30cm)	12"(30cm)
F	Clearance to outside corner: with <i>AstroCap</i> Termination Cap.	6"(15cm)	6"(15cm)
	Clearance to outside corner: with all other approved Termination Caps	12"(30cm)	12"(30cm)
G	Clearance to inside corner: with <i>AstroCap</i> Termination Cap	6"(15cm)	6"(15cm)
	Clearance to inside corner: with all other approved Termination Caps	12"(30cm)	12"(30cm)
н	Clearance to each side of center line extended above meter/regulator assembly	36"(90cm) <sup>a</sup>	*
J	Clearance to service regulator vent outlet	36"(90cm)	*
К	Clearance to non-mechanical air supply inlet to building or the combustion air inlet to any other appliance	12"(30cm)	9" (23cm)
L	Clearance to a mechanical air supply inlet (91cm) above if within 10' (3m) horizontally	72"(1.8m)	36"(90cm) <sup>b</sup>
М	Clearance above paved sidewalk or a paved driveway located on public property <sup>†</sup>	84"(2.1m) <sup>†</sup>	*
N	Clearance under veranda, porch, deck, or balcony‡	12"(30cm) <sup>‡</sup>	*

<sup>&</sup>lt;sup>1</sup> In accordance with current CSA B149.1, Natural Gas and Propane Installation Code
<sup>2</sup> In accordance with the current ANSI Z223.1/NFPA 54, National Fuel Gas Code

<sup>+</sup> A vent shall not terminate directly above a sidewalk or paved driveway winimm of two single family dwellings and serves both dwellings are Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor

<sup>\*</sup> Clearance in accordance with local installation codes and the requirements of the gas supplier 3 feet (91cm) within a height of 15 feet (4.5m) above the meter / regulator assembly

**b** 3 feet (91cm) above - if within 10 feet (3m) horizontally

#### 4" X 6-5/8" RIGID PIPE CROSS REFERENCE CHART

Components from different Manufacturers may not be mixed. Not All Rigid Pipe components are available directly from FPI.

Description	Simpson Direct Vent Pro <sup>®</sup>	*Selkirk Direct Temp™	*American Metal Products® Amerivent Direct	*Metal-Fab™ Sure Seal	*Security Secure- Vent®	*ICC Excel Direct	*Olympia Ventis DV***
6" Pipe Length-Galvanized	46DVA-06	4DT-6	N/A	4D6	SV4L6	TC-4DL6	VDV-0406
6" Pipe Length-Black	46DVA-06B	4DT-6B	N/A	4D6B	SV4LB6	TC-4DL6B	VDVB-0406
7" Pipe Length-Galvanized	N/A	N/A	4D7	N/A	N/A	N/A	N/A
7" Pipe Length-Black	N/A	N/A	4D7B	N/A	N/A	N/A	N/A
9" Pipe Length-Galvanized	46DVA-09	4DT-9	N/A	N/A	N/A	TC-4DL9	VDV-0409
9" Pipe Length-Black	46DVA-09B	4DT-9B	N/A	N/A	N/A	TC-4DL9B	VDVB-0409
12" Pipe Length-Galvanized	46DVA-12	4DT-12	4D12	4D12	SV4L12	TC-4DL1	VDV-0412
12" Pipe Length-Black	46DVA-12B	4DT-12B	4D12B	4D12B	SV4LB12	TC-4DL1B	VDVB-0412
18" Pipe Length-Galvanized	46DVA-18	4DT-18	4D18	4D18	SV4LA	TC-4DL18	VDV-0418
18" Pipe Length-Black	46DVA-18B	4DT-18B	4D18B	4D18B	SV4LA	TC-4DL18B	VDVB-0418
24" Pipe Length-Galvanized	46DVA-24	4DT-24	4D24	4D24	SV4L24	TC-4DL2	VDV-0424
24" Pipe Length-Black	46DVA-24B	4DT-24B	4D24B	4D24B	SV4LB24	TC-4DL2B	VDVB-0424
36" Pipe Length-Galvanized	46DVA-36	4DT-36	4D36	4D36	SV4L36	TC-4DL3	VDV-0436
36" Pipe Length-Black	46DVA-36B	4DT-36B	4D36B	4D36B	SV4LB36	TC-4DL3B	VDVCB-0436
48" Pipe Length-Galvanized	46DVA-48	4DT-48	4D48	4D48	SV4L48	TC-4DL4	VDV-0448
48" Pipe Length-Black	46DVA-48B	4DT-48B	4D48B	4D48B	SV4LB48	TC-4DL4B	VDVB-0448
60" Pipe Length-Galvanized	46DVA-60	4DT-60	N/A	N/A	N/A	N/A	N/A
60" Pipe Length-Black	46DVA-60B	4DT-60B	N/A	N/A	N/A	N/A	N/A
Adjustable Length 3"-10"-Galvanized	N/A	N/A	N/A	4DAL	N/A	TC-4DLT	N/A
Adjustable Length 3"-10"-Black	N/A	N/A	N/A	4DALB	N/A	TC-4DLTB	N/A
Adjustable Length 7)-Galvanized	N/A	N/A	4D7A	N/A	N/A	N/A	N/A
Adjustable Length 7"-Black	N/A	N/A	4D7AB	N/A	N/A	N/A	N/A
Extension Pipe 8-1/2"-Galvanized	46DVA-08A	N/A	N/A	N/A	N/A	N/A	N/A
Extension Pipe 8-1/2"-Black	46DVA-08AB	N/A	N/A	N/A	N/A	N/A	N/A
Adjustable Length 12"-Galvanized	N/A	N/A	4D12A	N/A	SV4LA12	TC-4dLSI	N/A
Adjustable Length 12"-Black	N/A	N/A	4D12A	N/A	SV4LBA12	TC-4dLSIB	N/A
Extension Pipe 16"-Galvanized	46DVA-16A	N/A	N/A	N/A	N/A	N/A	N/A
Extension Pipe 16"-Black	46DVA-16AB	N/A	N/A	N/A	N/A	N/A	N/A
45° Elbow-Galvanized	46DVA-E45	4DT-EL45	4D45L	N/A	N/A	TE-4DE45	VDV-EL0445
45° Elbow-Black	46DVA-E45B	4DT-EL45B	4DT-EL45B	N/A	N/A	TE-4DE45B	VDVB-EL0445
45° Elbow Swivel-Galvanized	See 46DVA-E45	N/A	N/A	4D45L	SV4E45	N/A	N/A
45° Elbow Swivel-Black	See 46DVA-E45B	N/A	N/A	4D45LB	SV4EB45	N/A	N/A
90° Elbow-Galvanized	46DVA-E90	4DT-EL90S	4DT-EL90S	N/A	N/A	TE-4DE90	VDV-EL0445
90° Elbow-Black	46DVA-E90B	4DT-EL90SB	4DT-EL90SB	N/A	SV4EBR90-1	TE-4DE90B	VDVB-EL0445
90° Elbow, Swivel-Galvanized	See 46DVA-E90	N/A	N/A	4D90L	SV4E90-1	N/A	N/A
90° Elbow, Swivel-Black	See 46DVA-E90B	N/A	N/A	4D90LB	wSV4EB90-1	N/A	N/A
90° Starter Elbow, Swivel-Galvanized	N/A	N/A	N/A	4D90A	N/A	N/A	N/A
Adaptor*	N/A	N/A	N/A	4D90L	N/A	N/A	VDV-UAA04
Cailing Command	L NI/A	4DT 00	4DCD	4DECD	CV4CD	TMA DDC	VDV CCD04
Ceiling Support	N/A	4DT-CSS	4DSP	4DFSP	SV4SD SV4CSB	TM4-RDS	VDV-SCR04
Cathedral Support Box	46DVA-CS	4DT-CSS	4DRSB	4DRS	SV4CSB	TM4-SDS	VDV-CSS04
Wall Support/Band	46DVA-WS	4DT-WS/B	4DWS	4DWS	SV4BM	TM-SWS	VDV-WS04
Offset Support	46DVA-ES	4DT-OS	N/A	N/A	SV4SU	TM-SOS	N/A
Wall Thimble-Black	46DVA-WT	4DT-WT	4DWT	4DWT	SV4RSM	N/A	VDV-WPT04
Wall Thimble Cover/Ceiling Support	46DVA-DC	N/A	N/A	N/A	SV4PF	N/A	N/A
Firestop Spacer	46DVA-FS	4DT-FS	4DFSP	4DFS	SV4BF	TM-4CS	VDV-FS04
Trim Plate-Black	N/A	4DT-TP	4DFPB	4DcP	SV4LA	TM-4TP	VDV-WTC04

<sup>\*</sup> Not available from Regency

Description	Simpson Direct Vent Pro <sup>®</sup>	*Selkirk Direct Temp™	*American Metal Products® Amerivent Direct	*Metal-Fab™ Sure Seal	*Security Secure- Vent®	*ICC Excel Direct	*Olympia Ventis DV***
Attic Insulation Shield 12"	46DVA-IS	N/A	4DAIS12	4DIS	SV4RSA	N/A	VDV-AIS04
Attic Insulation Shield - Cold Climates 36"	N/A	N/A	4DAIS12	N/A	N/A	TM-4AS	N/A
Basic Horizontal Termination Kit (A)	46DVA-KHA	4DT-HKA	4DHTK2	4DHTKA	SV-SHK	TM4-HTK	VDV-KW04
Horizontal Termination Kit (B)	N/A	4DT-HKB	4DHTK1	4DHTKB	SV-HK	TM4-HTK	VDV-K04
Vertical Termination Kit	N/A	4DT-VKC	4DHTK	4DHTK	SV-FK	N/A	N/A
		4DT VC					
High Wind Vertical Cap	46DVA-VCH	4DT-VC	N/A	N/A	N/A	TM-4VT	VDV-VCHW04
High Wind Horizontal Cap	N/A	N/A	N/A	N/A	N/A	TM-4DHT	N/A
Horizontal Square Termination Cap	46DVA-HC	4DT-HHC	4DHC	4DHT	SV4CHC	TM-4HT	VDV-HC04
Vertical Termination Cap	46DVA-VC	4DT-HVC	4DVC	4DVT	SV4CGV	N/A	N/A
Storm Collar	46DVA-SC	4DT-SC	4DSC	4DSC	SV4FC	TM-SC	VDV-SC04
Flashing - Flat Roof	46DVA-FF	N/A	N/A	N/A	N/A	N/A	N/A
Adjustable Flashing 0/12-6/12	46DVA-F6	4DT-AF6	4D12S	4DF	SV4STC14	TF-4FA	VDV-F0406
Adjustable Flashing 6/12-12/12	46DVA-F12	4DT-AF12	4D36S	4DF-12	SV4STC36	TF-4FB	VDV-SSO
Vinyl Siding Standoff	46DVA-VSS	4DT-VS	N/A	4DVS	SV4VS	TM-VSS	N/A
Vinyl Siding Shield Plate	N/A	4DT-VSP	N/A	N/A	SV4VS	N/A	N/A
Snorkel Termination 14"	46DVA-SNK14	4DT-ST14	l <sub>N/A</sub>	N/A	N/A	TM-4ST14	N/A
Snorkel Termination 36"	*46DVA-SNK36	4DT-ST36	N/A	N/A	N/A	TM-4ST36	N/A
Wall Firestop	46DVA-WFS	N/A	N/A	N/A	N/A	TM-4TR	VDV-FS04


<sup>\*</sup> Not available from Regency

FPI			
946-506/P	Vent Guard (Optional) for AstroCap	946-205	Vinyl Siding Shield for Riser Vent Terminal
**510-994	Rigid Pipe Adaptor (Must use with all rigid piping)	946-208/P	Vent Guard (Optional) for Riser Vent Terminal
640-530/P	Riser Vent Terminal	946-523/P	AstroCap Horizontal Cap
		946-206	Vinyl Siding Standoff for AstroCap

<sup>\*\*</sup>The rigid pipe adaptor is not required on the C34, C34E, U39, U39E, H15, H27, H35 & RC500E.

Note: When using Metal-Fab Sure Seal Rigid Piping - please note that the Adaptor (4DDA) must be used in conjunction with FPI Rigid Pipe Adaptor (510-994).

Offset Pipe Selection: Use this table to determine offset pipe leng						
Pipe Length	4" x 6-5/8" Venting					
(L)	Run (X)	Rise (Y)				
0" (0mm)	4-7/8" (124mm)	13-7/8" (340mm)				
6" (152mm)	8" (203mm)	16-1/2" (419mm)				
9" (229mm)	10-1/8" (257mm)	18-5/8" (473mm)				
12" (305mm)	12-1/4" (311mm)	20-3/4" (527mm)				
24" (610mm)	20-5/8" (524mm)	29-1/8" (740mm)				
36" (914mm)	29" (737mm)	37-1/2" (953mm)				
48" (1219mm)	37-7/16" (951mm)	45-15/16" (1167mm)				



For specific instructions on venting components - visit the manufacturers website listed below.

Simpson Direct Vent Pro: www.duravent.com

Selkirk Direct-Temp: www.selkirkcorp.com

American Metal Products: www.americanmetalproducts.com

Metal-Fab Sure Seal: www.mtlfab.com

Security Secure Vent: www.securitychimneys.com

Industrial Chimney Company: www.icc-rsf.com


Olympia Ventis DV: www.olympiachimney.com

Note: Horizontal runs of vent must be level, or have a 1/4" rise for every 1 foot of run towards the termination.

Never allow the vent to run downward - this could cause high temperatures and may present a possible fire hazard.

Olympia Ventis DV: www.olympiachimney.com

## RIGID PIPE VENTING SYSTEMS Horizontal or Vertical Terminations




#### **WARNING:**

Do not combine venting components from different venting systems.

However use of the AstroCap $^{\text{TM}}$  and FPI Riser is acceptable with all systems.

This product has been evaluated by Intertek for use with Duravent Direct-Vent , Selkirk Direct-Temp, Ameri Vent Direct venting and Security Secure Vent systems.



The FPI AstroCap<sup>™</sup> and FPI Riser Vent terminal are certified for installations using FPI venting systems as well as Simpson Dura-Vent® Direct Vent, American Metal Products Ameri Vent Direct Vent, Security Secure Vent®, Selkirk Direct-Temp. AstroCap<sup>™</sup> is a proprietary trademark of FPI Fireplace Products International Ltd. Dura-Vent® and Direct Vent are registered and/or proprietary trademarks of Simpson Dura-Vent Co. Inc.


#### VENTING ARRANGEMENTS HORIZONTAL TERMINATIONS FOR ALL VENTING SYSTEMS

The shaded areas in the Diagram below show all allowable combinations of vertical runs with horizontal terminations. Maximum one 90° elbow (two 45° elbows equal one 90° elbow).

## Propane and Natural Gas: Residential, Manufactured and Mobile Homes Installations

The venting arrangements diagrammed below, have a min. of 75% (flue loss) efficiency with Fan Off, as required for manufactured homes. (Actual efficiency may be as high as 85%)

May be installed in Manufactured (Mobile) Homes after first sale.




## VENTING ARRANGEMENTS VERTICAL TERMINATION SYSTEMS FOR RESIDENTIAL MANUFACTURED AND MOBILE HOMES

The shaded area in the Diagram below shows all allowable combinations of straight vertical and offset to vertical runs with vertical terminations. Maximum two 45° elbows.

All vertical and offset to vertical vent installations require Vent Restrictor Position "R" (Right). If the vent is ENCLOSED in a chase (min. size 9" x 9") maintain a 1-1/4" clearance to combustibles.

May be installed in Manufactured (Mobile) Homes after first sale.



Straight Vertical and Offset to Vertical Terminations use Vent Restrictor Position "R" (Right)

If you are terminating within this shaded area,
Vent Restrictor Position "R" (Right) must be used.

NOTE: See "Vent Restrictor Position" section for installation instructions for the Vent Restrictor Position.

#### **Venting Arrangements Examples:**

Example A) Venting has a horizontal termination.

A 7 ft. vertical run with 6 ft. horizontal run does not fall within the shaded area, and therefore is an allowable installation with the factory set vent restrictor position of "C".

Example B) Offset to Vertical Vent.

A 15 ft. vertical run with 4 ft. horizontal offset distance falls within the shaded area and is an allowable installation with Vent Restrictor Position "R" (Right).

#### Horizontal Venting with Two (2) 90° Elbows

#### One 90° elbow = Two 45° elbows.


Option	v	H + H1
A)	4' Min.	6' Max.
B)	5' Min.	7' Max.
C)	6' Min.	8' Max.

With these options, maximum total pipe length is 30 feet with minimum of 6 feet total vertical and maximum 8 feet total horizontal.

Please note minimum 1 foot between 90° elbows is required.

Lengths do not include elbow indicated.

Vent restrictor position C (fully open), refer to "Vent Restrictor Position" section.



#### Vertical Venting with Two (2) 90° Elbows

One 90° elbow = Two 45° elbows.


With these	V + V1	Н	٧	Option
pipe lengt of 6 feet to 8 feet tot Please betwee	2' Min.	4' Max.	1' Min.	A)
	3' Min.	5' Max.	2' Min.	B)
	4' Min.	6' Max.	3' Min.	C)
	5' Min.	7' Max.	4' Min.	D)
require	6' Min.	8' Max.	5' Min.	E)

With these options, max. total pipe length is 30 feet with min. of 6 feet total vertical and max. 8 feet total horizontal.

Please note min. 1 foot between 90° elbows is required.

Lengths do not include elbow indicated.

Vent restrictor position C (fully open), refer to "Vent Restrictor Position" section



#### DV STOVE HORIZONTAL VENT KIT

DV 2 ft. Stove Vent Kit (Part # 946-116) and DV 4 ft. Stove Vent Kit (946-216) include all the parts needed to install the C34 with minimum horizontal and vertical vent dimensions. For installations that require longer

vertical and/or horizontal vents use the Dura-Vent system as shown in "Dura-Vent Termination Kit" & "Dura-Vent Venting Components" section.

#### Qty. Description


- Rigid Pipe Section (Kit # 946-116: 2 ft. (1.2 m) length, Kit # 946-216: 4 ft. (1.2 m) length), 6-1/2" (165 mm) inside diameter
- 2. 1 Flex Liner, compressed aluminum 2 ply liner, 4" (102 mm) inside diameter
- 3. 4 spring spacers
- 4. 1 90 deg. Elbow
- 5. 1 Adjustable pipe section 13-1/2" to 24" (343 mm x 610 mm), 2 pieces
- 6. 1 Thimble Cover
- 7. 1 Wall Thimble (2 pcs.)
- 8. 1 Adapter
- 9. 1 AstroCap Termination Cap
- 10 2 Trim Collar
- 11. 1 tube of Mill-Pac, high temperature sealant
- 12. 12 Screws, #8 x 1/2" Self tapping, Stainless Steel
- 13. 14 Screws, #8 x 1/2" Self tapping, Black
- 14. 4 Screws #8 x 1-1/2" Drill Point, Black
- 15. 4 Screws #8 x 1-1/2" Drill Point, Stainless Steel
- 17. 8 Wood screws #8 x 1"



946-206Vinyl Siding Standoff for AstroCap

#### Note:

- a) Liner sections should be continuous without any joints or seams.
- b) This is an approved system, therefore components in this system must not be substituted for any other manufacturer's products.



Wall Thimble

(in Canada)

#### DV STOVE HORIZONTAL VENT KIT INSTALLATION

Review the following sequence of instructions which are typical of most installations. The sequence may vary depending on wall thickness.


See "Locating Your Gas Stove" to "Exterior Vent Terminal Locations" sections for vent location and clearance dimensions.

 Set the unit in its desired location. Check to determine if wall studs will be in the way of the venting system, adjust location until all clearances are met and there are no obstructions.

Note: A1-1/2"(38 mm) clearance around the outer pipe must be maintained except that only a 1" (25 mm) clearance is needed at the termination end.

#### IMPORTANT:

Do not locate termination hood where excessive snow or ice buildup may occur. Be sure to check vent termination area after snow falls, and clear to prevent accidental blockage of venting system. When using snow blowers, make sure snow is not directed towards vent termination area.



- Assemble a trial fit to determine the vertical center-line for the vent termination.
  - a) Cut a 9-1/2" x 9-1/2" (241 mm x 241 mm) square hole on both the interior and exterior wall.
  - Install wall thimbles on both interior and exterior wall with 4 wood screws (#8 x 1") per thimble.
  - c) Attach the 2-piece adjustable pipe section to the vent terminal and slide into position from the exterior. The larger diameter end of the adjustable pipe goes to the vent terminal.
  - d) Install the 90° elbow onto the adjustable pipe to determine the vertical centerline of the starter collar on the unit.

Note: if the centerline cannot be met, the adjustable sections will have to be cut.

Cap

 $(\mathbf{C})$ 


Qty: 4

Cap

Cut the 2 ft. or 4 ft. section of rigid pipe to length. Ensure that the pipe length when cut will seat onto both the starter collar and the 90° elbow. Crimped section of rigid pipe seats into the 90° elbow. Only cut the uncrimped side of pipe.

Dismantle all pipe sections including vent terminal.


- 3. Attach the 4" dia. flex liner to the vent terminal ensuring that the flex overlaps the collar of the vent terminal by a minimum of 1-3/8"(35 mm). Use Mill-Pac to seal and secure with 3 of the #8 x 1/2" screws (stainless steel).
- 4. Attach the adjustable pipe section to the vent terminal using Mill-Pac and attach with 3 of the #8 x 1/2" screws (stainless steel).



Hint: Apply the sealant (Mill-Pac) to the outer pipe before connecting the inner pipe.


Note: The pipe seam should be facing down.

Note: To make the installation more aesthetically pleasing, we recommend framing out a square that the cap can be mounted on.



Note: If installing termination on a siding covered wall, a vinyl siding standoff or furring strips must be used to ensure that the termination is not recessed into the siding. For vinyl siding standoff installation refer to the Dura-Vent Termination instructions.

5. Slide the partially connected pipe and vent terminal assembly through the wall thimbles (from the exterior into the interior) and secure the cap to the exterior wall with 4 of the supplied screws (#8 x 1-1/2" drill point, stainless steel). Note: pilot holes will need to be drilled through the wall thimble on all 4 corners.



Note: The four screws provided for the vent cap should be replaced with appropriate fasteners for stucco, brick, concrete, or other types of sidings.

- 6. A bead of non-hardening mastic should be run around both the termination and vinyl siding standoff to prevent water from entering and to make a tight seal between the cap and the standoff.
- 7. Stretch the 4" dia. flex liner out fully and get a trial fit of the liner onto the 4" dia. starter collar.
- 8. Cut the 4" dia. flex liner to the desired size.

Hint: leave an extra 12" to 16" of length, this will make the final assembly easier to work with.

- 9. Secure the 4" dia. flex liner to the 4" adapter with Mill-Pac and 3 of the #8 x 1/2" screws (stainless steel).
- 10 Slide the decorative Thimble Cover over the pipe sections and secure with 4 screws (#8 x 1-1/2" drill point, black) to the wall.

Slide the trim collar over the adjustable pipe sections to cover the joint of the telescopic section.

- 11. Slide the 90° elbow (crimp end up) and the 2 ft. or 4 ft. pipe section (crimp end up) over the 4" dia. flex liner.
- 12. Install the spring spacers onto the pipe

- 13. Secure the 4" dia. flex liner with adapter onto the stove collar. Put a bead of Mill-Pac around the appliance adapter and secure with 3 screws (#8 x 1/2, stainless steel).
- 14. Attach the pipe section onto the starter collar by sealing with Mill-Pac securing with 3 of the #8 x 1/2" (black) screws. Pipe seams should be facing the wall.
- 15. Attach the 90° elbow onto the pipe section by sealing with Mill-Pac securing with 3 of the #8 x 1/2" screws (black).
- 16. Slide the adjustable pipe section onto the 90° elbow. The flex may have to be compressed back in order for the adjustable pipe to properly mate to the elbow. Seal with Mill-Pac and secure with 3 of the #8 x 1/2" screws (black). Pipe seams facing down.
- 17. Install the trim collar over the starter collar and secure with a #8 x 1/2" screw (black).

If the pipe needs to be touched up, use only Stove Brite High Temperature Metallic Black Stove Paint.

NOTE: All inner/outer joints must be sealed with Mill-Pac.

#### DURA-VENT TERMINATION KIT

## Planning Your Dura-Vent Installation

There are two basic types of Dura-Vent Direct Vent System installations: horizontal termination and vertical termination. Confirm the maximum horizontal run and maximum vertical rise from the Diagrams in "Venting Arrangments" section.

When planning your installation, it will be necessary to select the proper length of vent pipe for your particular requirements. For horizontal installations, determine the minimum clearance from the rear of the unit to the wall. It is also important to note the wall thickness. (The wall thimble is suitable for  $2 \times 4$  or  $2 \times 6$  wall construction.) Select the amount of vertical rise desired for "vertical-to-horizontal" type installations.

Warning: Always maintain required clearances (airspaces) to nearby combustibles to prevent a fire hazard. Do not fill air spaces with insulation.

The minimum clearance of 1-1/4" (32 mm) is required between the outer wall of the vent pipe and nearby combustible surfaces. Be sure to check the vent termination clearance requirements from decks, windows, soffits, gas regulators, air supply inlets and public walkways as specified in the "Exterior Vent Terminal Locations" section and in your local building codes.

To determine the length of vent pipe required for vertical installations, measure the distance from the unit flue outlet to the ceiling, the ceiling thickness, the vertical rise in an attic or second storey, and allow for sufficient vertical height above the roof line.

For multi-storey applications, fire stops are required at each floor level. If an offset is needed, additional pipe, elbows and supports will be required.

You will require the following Dura-Vent venting components with your new CLASSIC Direct Vent Freestanding Gas Stove. Please review your product to make sure you have everything you need. In the event that you are missing any part, contact your dealer.


Note: These are the minimum components required. Other parts may be required for your particular installation. See "Rigid Pipe Venting Components List" section.

If installing termination on a siding covered wall, a vinyl siding standoff or furring strips can be used in order to ensure that the termination is not recessed into siding.

The vinyl siding standoff is required for walls with vinyl siding.

#### Basic Horizontal Kit


- 90° Elbow
- 1 Wall Thimble Cover
- 1 Horiz. Sq. Term. Cap



The FPI AstroCap<sup>™</sup> and FPI Riser Vent terminal are certified for installations using FPI venting systems as well as Simpson Dura-Vent® Direct Vent, American Metal Products Ameri Vent Direct Vent, Security Secure Vent®, Selkirk Direct-Temp. AstroCap<sup>™</sup> is a proprietary trademark of FPI Fireplace Products International Ltd. Dura-Vent® and Direct Vent are registered and/or proprietary trademarks of Simpson Dura-Vent Co. Inc.

#### DURA-VENT HORIZONTAL INSTALLATIONS

- Set the unit in its desired location. Check to determine if wall studs or roof rafters are in the way when the venting system is attached. If this is the case, you may want to adjust the location of the unit.
- 2. Direct Vent pipe and fittings are designed with special twist-lock connections to connect the venting system to the appliance flue outlet. A twist-lock appliance adaptor is installed on the unit at the factory. Assemble the desired combination of pipe and elbows to the appliance adaptor with pipe seams oriented



towards the wall or ceiling, as much out of view as possible. The final positioning of the pipe and 90° elbow assembly is determined by the mounting orientation of the adaptor on the stove and twist-locked for a solid connection.

#### Note:

a) Twist-lock procedure: Four indentations, located on the female ends of pipes and fittings, are designed to slide straight onto the male ends of adjacent pipes and fittings, by orienting the four pipe indentations so they match and slide into the four entry slots on the male ends (Diagram 1). Push the pipe sections completely together, then twist lock one section clockwise approximately one-quarter turn, until the two sections are fully locked.

The female locking lugs will not be visible from the outside on the Black Pipe or fittings. They may be located by examining the inside of the female ends. Apply sealant "Mill-Pac" to inner pipe and to outer pipe on every twist-lock joint.





Diagram 1

b) Horizontal runs of vent must be supported every three feet. Wall straps are available for this purpose. 3. With the pipe attached to the stove, slide the stove into its correct location, and mark the wall for a 10" x 10" (inside dimensions) square hole. The center of the square hole should line up with the centerline of the horizontal pipe, as shown in Diagram 2. Cut and frame the 10-inch square hole in the exterior wall where the vent will be terminated. If the wall being penetrated is constructed of non-combustible material, i.e. masonry block or concrete, a 7" diameter hole is acceptable.




#### Note:

- a) The horizontal run of vent must be level, or have a 1/4 inch rise for every 1 foot of run towards the termination. Never allow the vent to run downward. This could cause high temperatures and may present the possibility of a fire.
- b) The location of the horizontal vent termination on an exterior wall must meet all local and national building codes, and must not be blocked or obstructed. See Diagram 10 in "External Vent Terminal Locations" section.

#### c) Snorkel Terminations:

For installations requiring a vertical rise on the exterior of the building, 14-inch and 36-inch tall Snorkel Terminations as shown in Diagram 3 are available, as well as the standard Riser Vent, see Diagram 3a. Follow the same installation procedures as used for standard Horizontal Termination. NEVER install the snorkel upside down.



#### **Below Grade Installation**

If the Snorkel Termination must be installed below grade, i.e. basement application, proper drainage must be provided to prevent water from entering the Snorkel Termination. Refer to Diagram 4. Do not attempt to enclose the Snorkel within the wall, or any other type of enclosure.

Snorkel


Window Well

Adequate drainage

Gravel


Diagram 4

4. Attach the Vinyl Siding Standoff (if required) to the Horizontal Vent Termination, but first run a bead of non-hardening mastic around its outside edges, so as to make a seal between vent cap and the standoff. Install the Vinyl Siding Standoff between the vent cap and the exterior wall and attach with the four wood screws provided. Seal around the Vinyl Siding Standoff on all four sides. Diagram 5. The arrow on the vent cap should be pointing up. Insure that the 1-1/4" clearances to combustible materials are maintained. See Diagram 5.



Note: If installing termination on a siding covered wall, a vinyl siding standoff or furring strips must be used to ensure that the termination is not recessed into the siding. The four wood screws provided should be replaced with appropriate fasteners for stucco, brick, concrete, or other types of sidings.

- 5. Before connecting the horizontal run of vent pipe to the vent termination, slide the black decorative wall thimble cover over the vent pipe, then slide the Wall Thimble over the vent pipe.
- 6. Slide the appliance and vent assembly towards the wall carefully inserting the vent pipe into the vent cap assembly. It is important that the vent pipe extends into the vent cap a sufficient distance so as to result in a minimum pipe overlap of 1-1/4 inches. Secure the connection between the vent pipe and the vent cap by attaching the two sheet metal strips extending from the vent cap assembly into the outer wall of the vent pipe. Use the two sheet metal screws provided to connect the strips to the pipe section. Bend any remaining portion of the sheet metal strip back towards the vent cap, so it will be concealed by the decorative wall thimble cover. See Diagram 6.
- 7. Install Wall Thimble in the center of the 10" square and attach with wood screws (in Canada).



8. Slide the decorative wall thimble up to the wall surface being careful not to scratch the paint and attach with screws provided. Apply decorative brass or chrome trim if desired. See Diagram 7.




Diagram 7


#### **VERTICAL TERMINATION**

1. Maintain the 1-1/4" clearances (airspaces) to combustibles when passing through ceilings,


walls, roofs, enclosures, attic rafter, or other nearby combustible surfaces.

Do not pack airspaces with insulation. Check "Venting Arrangements" section for the maximum vertical rise of the venting system and the maximum horizontal offset limitations.

2. Set the gas appliance in its desired location. Drop a plumb bob down from the ceiling to the position of the appliance flue exit, and mark the location where the vent will penetrate the ceiling. Drill a small hole at this point. Next, drop a plumb bob from the roof to the hole previously drilled in the ceiling, and mark the spot where the vent will penetrate the roof.



Determine if ceiling joists, roof rafters or other framing will obstruct the plumber's venting system. You tape may wish to relocate connected members.



to wall strap wal 45 strap **Elbows** Firestop Diagram 9 Spacer

Support Box/Wall Thimble in a flat ceil-

ing, cut a 10-inch square hole in the ceiling centered on the hole drilled in Step 2. Frame the hole as shown in Diagram 10.




Diagram 10

- 4. Assemble the desired lengths of black pipe and elbows necessary to reach from the appliance adaptor up through the Round Support Box. Ensure that all pipes and elbow connections are in the fully twist-locked position and sealed.
- 5. Cut a hole in the roof centered on the small drilled hole placed in the roof in Step 2. The hole should be of sufficient size to meet the minimum requirements for clearance to combustibles of 1-1/4". Slip the flashing under the shingles (shingles should overlap half the flashing) as per Diagram 11.



Diagram 11: The upper half of the flashing is installed under the roofing material and not nailed down until the chimney is installed. This allows for small adjustments.


Continue to assemble pipe lengths.

**Note:** If an offset is necessary in the attic to avoid obstructions, it is important to support the vent pipe every 3 feet, to avoid excessive stress on the elbows, and possible separation. Wall straps are available for this purpose. See Diagram 9.

Galvanized pipe and elbows may be utilized in the attic as well as above the roofline. The galvanized finish is desirable above the roofline due to its higher corrosion resistance.

Continue to add pipe sections through the flashing until the height of the vent cap meets the minimum height requirements specified in Diagram 12 or local codes. Note that for steep roof pitches, the vertical height must be increased. A poor draft, or down drafting can result from high wind conditions near big trees or adjoining roof lines, in these cases, increasing the vent height may solve the problem.

- Ensure vent is vertical and secure the base of the flashing to the roof with roofing rails, slide storm collar over the pipe section and seal with a mastic.
- **8.** Install the vertical termination cap by twist locking it.



Roof Pitch	Minimum Vent Height		
	Feet	Meters	
flat to 7/12	2	0.61	
over 7/12 to 8/12	2	0.61	
over 8/12 to 9/12	2	0.61	
over 9/12 to 10/12	2.5	0.76	
over 10/12 to 11/12	3.25	0.99	
over 11/12 to 12/12	4	1.22	
over 12/12 to 14/12	5	1.52	
over 14/12 to 16/12	6	1.83	
over 16/12 to 18/12	7	2.13	
over 18/12 to 20/12	7.5	2.29	
over 20/12 to 21/12	8	2.44	

#### Notes:

- a) For multi-storey vertical installations, a Ceiling Fire stop is required at the second floor, and any subsequent floor. See Diagram 13. The opening should be framed to 10 " x 10" inside dimensions, in the same manner as shown in Diagram 10.
- b) Any occupied areas above the first floor, including closets and storage spaces, through which the vertical vent passes, must be enclosed.





Diagram 13

#### **Offset Chart**

	GS 6"(152mm) Nominal Diameter ID							
	Offset		Pipe Length (L)		Height			
Į.	nches	mm	inches	mm	inches	mm		
	4 3/4	121	0	0	13 1/4	337		
	9	229	6	152	17 1/2	445		
	11 1/4	286	9	229	19 1/2	495		
	13 1/4	337	12	305	21 3/4	552		
	21 3/4	552	24	610	30 1/4	768		
	30 1/4	768	36	914	39	991		
	38	965	48	1219	47	1194		




#### **CATHEDRAL CEILINGS**

## Round Support (RDS) & Square Support (SQS)

If your home has a cathedral ceiling (no attic space between the ceiling and the roof), install the chimney and support as follows.

- Situate the chimney in a convenient location as near as possible to the appliance outlet. Cut and frame a hole in the roof for the support. The sides of this hole must be vertical with 1-1/4" clearance.
- Place the support in the opening. Lower it to the correct height as determined by the table and Diagram below.



Slope	"X"	
0/12 -2/12	4"	
2/12 -7/12	5-1/2"	
7/12 -12/12	6-3/4"	
12/12 - 24/12	7-1/2"	
24/12+	12-1/2"	

Using a level, make sure the support is vertical. If the support extends above the roof, cut it flush with the top of the roof. Nail the support to the frame opening using (8. 3" spiral nails or #8 x 1-1/2" screws.

## Note: If you are using a 6" square support you may find it difficult to screw it in place because it is fairly small inside.

Simpson Dura-Vent has provided angle brackets with this support which can be screwed to the outside of the support box and nailed to surrounding framing as required. Use a minimum of four #8 x 1/2" screws per bracket. In some cases these brackets may need to be trimmed (e.g.: to fit under a flashing). Place the Finish Collar around the support and fasten it to the ceiling using the screws provided.

- Use appropriate roof flashing. Place the flashing under the upper shingles and on top of the lower shingles approximately half of the flashing should be under the shingles.
- 4. Assemble the desired lengths of Black Pipe and Elbows necessary to reach from the appliance adaptor up through the support box and flashing to proper height as per Diagram 12, local codes or "Exterior Vent Terminal Locations" section. Ensure that all pipe and elbow connections are in their fully twist lock position.
- Ensure vent is vertical and secure flashing to the roof with roofing nails. Slide the storm collar over the pipe section and seal with a mastic.
- 6. Twist lock the vent cap on to the last section.

## Support extensions - Round (RDSE) or square (SQSE)

Steep pitched cathedral ceilings may require the use of a support extension. This piece fits down inside the support and can be adjusted to increase the support's length by up to 22". The extension is attached to the support using the eight metal screws provided. Be sure there is at lease a 2-inch overlap where the extension joins the support.

# CONVERTING CLASS-A METAL CHIMNEY TO DIRECT VENT SYSTEM

#### **General**

Approved for US Installations Only. The use of an existing chimney as an air intake is not covered under the Z21.88 test methods and the resulting ITS/WHI product certification. The code Authority Having Jurisdiction must be consulted prior to proceeding with this installation method.

A) Through an existing Class A metal chimney going through the ceiling: A typical conversion of this type is shown in Diagram 1. The concept of direct vent conversion is to connect an adaptor to an Underwriters Laboratories (UL) listed 4 inch diameter aluminum flex pipe which is then passed down through the center of the existing Class A metal chimney system. Three sizes of Top Adaptors are available from Simpson Dura-Vent. The Retro Connector is attached to the bottom of the flex pipe. The Top Adaptor and the Retro Connector are attached to the existing chimney with sheet metal screws. The appliance is then connected to the chimney with appropriate black direct vent pipe and an adjustable length section.

Prior to installation and connection of the vent system to a Class A chimney must be inspected and thoroughly cleaned by a qualified service person, such as a certified chimney sweep or home inspection service.


The direct vent system must not be connected to a damaged Class A chimney.

For Class A chimneys, clean out doors and caps or plugs for clean out tee fittings and ash dumps shall be secured in place and sealed before installing a Direct Vent system within the chimney.

If the appliance shuts off during operation, contact a qualified service person to determine if a negative pressure and/or leaky chimney condition exists. Do not operate the appliance until the problem is corrected.

## Converting a Factory Built Metal Chimney

- 1. Remove the existing chimney cap.
- Measure the distance from the top end of the chimney to the bottom of the ceiling support box, add 3" (76 mm) to this measurement, and cut a section of the 4" flex pipe to that length (the flex should already be extended to its nominal length).
- 3. Connect the end of the flex pipe section to the underside of the Top Adaptor using 3 sheet metal screws. Diagram 2.
- 4. Pass the flex pipe down through the center of the chimney system, and center the adaptor on the top of the chimney pipe. Drill four 1/8" diameter holes through the adaptor and into the chimney top. Insure that you are in fact, drilling into the metal on the chimney. Twist lock the Termination Cap onto the Adaptor. (Diagram 3 and 4).
- 5. Pull the flex pipe down through the ceiling support box, until it protrudes approximately 3" (76 mm). Connect the flex pipe to the Retro Connector by slipping it into the 4-3/4" diameter sleeve on the top side of the Connector. Use 3 sheet metal screws to assemble these two parts.
- Push the flex pipe back up into the ceiling support box, center the Retro Connector, and attach it to the support box, or decorative sleeve for double wall solid packed pipe, with the sheet metal screws (supplied). The holes in the Retro Connector are prepunched. Diagram 5.



7. The connection between the appliance and the Retro Connector may be completed with sections of black direct vent pipe, together with an adjustable length.





Diagram 2






Diagram 4




Diagram 5

# SYSTEM DATA (For 0 to 4,500 feet altitude)

Orifice Sizes:

**Burner** Natural Gas #36 **Burner** Propane #52

Max. Input Rating

Natural Gas 32,000 Btu/h Propane 29,000 Btu/h

Min. Input Rating

Natural Gas 21,000 Btu/h Propane 23,000 Btu/h

Supply Pressure

 Natural Gas
 min.
 5.0" w.c

 max.
 14.0" w.c.

 Propane
 min.
 11.0" w.c.

 max.
 14.0" w.c.

Manifold Pressure High

Natural Gas 3.5" w.c. Propane 10" w.c.

**Manifold Pressure Low** 

Natural Gas 1.6" w.c. Propane 6.4" w.c.

Electrical: 115V\_60 Hz less than 2 amp

Circulation Fan: 75/125 CFM. Log Set: Ceramic fiber, 4 per set.

# **Output capacity:**

The efficiency rating of the appliance is a product thermal efficiency rating determined under continuous operating conditions and was determined independently of any installed system.

## **GAS CONNECTION**

The gas connection is a 3/8" x 18" long flexible pipe. This is supplied and installed at the left rear of the unit. See "Unit Dimensions" section for Diagram. The gas line can be rigid pipe or to make installation easier, use a listed flexible connector and manual shutoff valve if allowed by local codes, or copper if approved. For minimum and maximum supply pressure see the System Data table.

Note: During any pressure testing of the gas supply piping system that exceeds test pressures of 1/2 psig, this appliance and its individual shutoff valve must be disconnected from the piping system. If test pressures equal to or less than 1/2 psig are used then this appliance must be isolated from the piping system by closing its individual manual shutoff valve during the testing.

## **HIGH ELEVATION**

This unit is approved in Canada for altitude 0 to 4500 ft. (CSA 2.17-2017) with the orifice supplied.

# GAS PIPE PRESSURE TESTING

The appliance must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig. (3.45 kPa). Disconnect piping from valve at pressures over 1/2 psig (14" w.c.).

The manifold pressure is controlled by a regulator built into the gas control, and should be checked at the pressure test point.


Note: To properly check gas pressure, both inlet and manifold pressures should be checked using the valve pressure ports on the valve.


- 1. Make sure the valve is in the "OFF" position.
- 2. Loosen the "IN" (# 7) and/or "OUT" (# 7) pressure tap(s), turning counterclockwise with a 1/8" wide flat screwdriver.
- 3. Attach manometer to "IN" and/or "OUT" pressure tap(s) using a 5/16" ID hose.
- 4. Light the pilot and turn the valve to "ON" position.
- 5. The pressure check should be carried out with the unit burning and the setting should be within the limits specified on the safety label.
- When finished reading manometer, turn off the gas valve, disconnect the hose and tighten the screw (clockwise) with a 1/8" flat screwdriver.
   Screw should be snug, but do not over tighten.

# 38 installation

# **SIT 829 VALVE DESCRIPTION**

- 1. Gas on/off knob
- 2. Electronically Operated Hi/Lo
- 3. Pilot Adjustment
- 4. Thermocouple Connection option
- 5. Outlet Pressure Tap
- 6. Inlet Pressure Tap
- 7. Pilot Outlet
- 8. Main Gas Outlet
- 9. Alternative TC Connection Point






# DC SPARKER BATTERY REPLACEMENT

1. Open door on pedestal or heat shield with legs base.

Remove two (2) screws in locations shown below to remove access panel.

2. Install the replacement battery into the DC Sparker Box by opening the battery compartment.

**NOTE**: The battery in the DC Sparker Box will need to be replaced annually.



Pedestal base shown



# **DOOR INSTALLATION**

# **Door Handle Assembly**



Diagram 1

2. Unscrew and turn the door retaining clip outwards, then re-tighten the screw (Diagram 2).




Diagram 2

# Safety Screen Installation / Removal

1. Door will be packaged with door retaining clip facing inwards (Diagram 1). 3. Install slotted brackets (found in the manual pack) to the back of the door with two (2) screws on each side as shown in Diagram 3.





After

Diagram 3

4. Attach door handle to door by installing the handle through the hole on the left upper corner (Diagram 4). Position the handle in the 8 O-clock positions, then tighten with 14mm (9/16") wrench.





Diagram 4

Place the door onto the door hinges. Put the hinge cover caps on top of hinges to complete the door (Diagram 5).



Note: The bottom of the door may scrape the ash lip. In this case place the spacers provided on the door hinges of the unit before placing the door.

# 40 installation

Once the door has been placed on the hinge pins, secure the door to the unit by screwing the retaining clip to the lower left corner of the unit (Diagram 6).



Diagram 6

7. To install the safety screen, hook the tabs on the safety into the slotted brackets on either side of the door (Diagram 7).



Diagram 7

8. To remove the safety screen, lift up slightly and pull forward.

# LOG INSTALLATION

WARNING: Dangerous operating conditions may occur if these logs are not positioned in their approved locations. Read the instructions below carefully and refer to the Diagrams. If logs are broken do not use the unit until they are replaced. Broken logs can interfere with the pilot and burner operation.

The gas log kit contains the following:

- a) Front Log
- b) Rear Log
- c) Small Cross Logs (2.
- d) Bag of embers
- e) Bag of rockwool
- Bag of platinum embers & Embaglow (supplied with packaged manual)
- 1. Remove securing screw from bracket as shown.




Diagram 1

# DO NOT TRY TO TURN THE DOOR HANDLE! IT IS NOT DESIGNED TO BE MOVED.

Note: The door must be kept closed at all times, except during maintenance. The unit must never be operated without the glass in the door, or with the door open.

- Remove the glass frame from the stove by removing four hex nuts (support glass so it doesn't fall out). See Diagram 1.
- Ensure that the front and rear deflectors are installed.
- Remove the logs from the box and carefully unwrap them. The logs are fragile, handle with care. Do not force into position.
- Place the rear log on the rear log support pins in the back of the unit. The flat side of the log facing the back of the unit. Carefully push the log down onto the pins. See Diagram 3.





Diagram 2

- Place the front log in the front of the unit, aligning the holes on the underside of the log with the log support pins in the front of the unit. Carefully push the log down onto the pins. See Diagram 3.
- Place the cross logs on top of the larger logs aligning the holes on the underside of the cross log with the log pins in the larger logs. See Diagrams 3 & 4. Carefully push the cross logs onto the pins.



Cross log support pin
Front deflector
Burner

Diagram 4

8. Distribute the embers along the mesh ember tray but do not cover the burner ports. (Burner ports are the little holes on the top of the burner tube.) Pull off ember size pieces from the rock wool. Gently place the pieces on top of the embers. See Diagram 5.

Do not put the rock wool directly on the burner. Before putting the glass back on, turn the unit on as per lighting instructions in this manual. Watch the flame to see if it flows smoothly around from one end to the other. (Use Extreme Caution and ensure proper light off of burner.)

 Separate platinum embers and place on the mesh ember tray alongside embers. Avoid stacking platinum embers. The Embaglow embers may be put on top of the platinum embers as desired. Note: Do not put any type of embers on the rear burner. This can only be installed on the front portion of the burner.




Diagram 5

Note: If the flame hesitates at any point, check the area of hesitation and see if there is an ember or rock wool blocking a burner port or ports. If so, move the obstruction and then check the flame flow again.

 Replace the glass. Secure door in the closed position using the door securing bracket and the screw provided, Figure 1. See door and glass frame instructions.

Note: Door securing bracket is there for safety.

# **DOOR AND GLASS FRAME**

The glass frame fastens with four screws.
 See Diagram 1.




Diagram 1


Note: The unit must never be operated without the glass in place (One exception is made during the log and ember installation.)

2. The securing bracket keeps the door closed.


# 42 installation

# SAFETY SCREEN INSTALLATION / REMOVAL

 Install slotted brackets (found in the manual pack)to the back of the door with 2 screws on each side as shown below.



- To install the safety screen, hook the tabs on the safety screen into the slotted bracket on either side of the glass door.
- 3. To remove the safety screen, lift up slightly and pull forward.



# REMOTE CONTROL INSTALLATION

Use the Regency® Remote Control Kit supplied with this unit. Use of other systems may void your warranty.

The remote control kit comes with a hand-held transmitter, a receiver and a wall mounting plate.

# CAUTION Do not wire millivolt remote control wires to the 120V AC wires

 Install 3 AAA alkaline batteries in transmitter and 4 AA alkaline batteries in the receiver. Install the receiver and its cover in the wall. Switch the remote receiver to "remote" mode. The remote control is now ready for operation.

# **OPTIONAL WALL THERMOSTAT**

A wall thermostat may be installed if desired. Connect the wires as per the wiring Diagrams. Note that the wires are connected to the "TH" on the gas valve. Use table below to determine the maximum wire length:

Note: Preferable if the thermostat is installed on an interior wall.

Regency® offers an optional programmable thermostat but any 250-750 millivolt rated non-anticipator type thermostat that is CSA, ULC or UL approved may be used.

# **CAUTION**

Do not connect the millivolt wall thermostat wires to the 120V wires.

Thermostat Wire Table			
Recommended Maximum Lead Length (Two-Wire) When Using Wall Thermostat (CP-2 System)			
Wire Size	Max. Length		
14 GA.	50 Ft.		
16 GA.	32 Ft.		
18 GA.	20 Ft.		
20 GA.	12 Ft.		
22 GA.	9 Ft.		

# **FINAL CHECK**

Before leaving this unit with the customer, the installer must ensure that the appliance is firing correctly. This includes:

- Clocking the appliance to ensure the correct firing rate (rate noted on label) at 15 minutes.
- 2. If required, adjusting the primary air to ensure that the flame does not carbon. First allow the unit to burn for 15 min. to stabilize.
- 3. Check for proper draft.

# CAUTION

Any alteration to the product that causes sooting or carboning that results in damage to the exterior facia is not the responsibility of the manufacturer.

# **WIRING DIAGRAM**

This heater does not require a 120V A.C. supply for operation. In case of a power failure, the burner switch and the optional remote control/thermostat will continue to operate.

However, a 120V A.C. power supply is needed for the optional fan/blower operation.


Note: If optional fan is not purchased, Batteries are required in both remote receiver (4 x AA Batteries) & remote hand held (3 x AAA batteries) in order to operate appliance using the remote control.

# WARNING:

Electrical Grounding Instructions

This appliance is equipped with a three pronged (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. Do not cut or remove the grounding prong from this plug.

CAUTION: Ensure that the wires do not touch a hot surface and are away from sharp edges.




# 44 operating instructions

# **PILOT ADJUSTMENT**


Periodically check the pilot flames. Correct flame pattern has three strong blue flames: 1 flowing around the thermopile, 1 around the thermocouple and 1 flowing across the burner (it does not have to be touching the burner).

Note: If you have an incorrect flame pattern, contact your Regency® dealer for further instructions.



Top View of pilot flame

Incorrect flame pattern will have small, probably yellow flames, not coming into proper contact with the rear burner or thermopile or thermocouple.




Top View of pilot flame

# **AERATION ADJUSTMENT**

This adjustment is performed by the installer and is primarily used in installations at high elevations. Push in for a yellow flame, or pull out for a bluer flame. The burner aeration is factory set but may need adjusting due to either the local gas supply or altitude.

Caution: Carbon will be produced if air shutter is closed too much.

Note: Aeration Adjustment should only be performed by an authorized Regency® Installer at the time of installation or service.



## **FIRST FIRE**

The first fire in your stove is part of the paint curing process. To ensure that the paint is properly cured, it is recommended that you burn your fireplace for at least four (4) hours the first time you use it with the fan on. When first operated, the unit will release an odour caused by the curing of the paint, the burning off of any oils remaining from manufacturing. Smoke detectors in the house may go off at this time. Open a few windows to ventilate the room for a couple of hours.

The glass panel may require cleaning after the unit has cooled down.

# DO NOT ATTEMPT TO CLEAN THE GLASS WHILE IT IS HOT.

Note: Whentheglassis cold and the appliance is lit, it may cause condensation and fog the glass. This condensation is normal and will disappear in a few minutes as the glass heats up.

During the first few fires, a white film may develop on the glass front as part of the curing process. The glass should be cleaned or the film will bake on and become very difficult to remove. Use a non-abrasive cleaner and NEVER clean the glass while it is hot.

# DO NOT BURN THE APPLIANCE WITHOUT THE GLASS FRONT IN PLACE.

# OPERATING INSTRUCTIONS

- Read and understand these instructions before operating this appliance.
- Check to see that all wiring is correct and enclosed to prevent possible shock.
- 3. Check to ensure there are no gas leaks.
- Make sure the glass in the door frame is properly positioned. Never operate the appliance with the glass removed.
- 5. Verify that the venting and cap are unobstructed.
- Verify log placement. If the pilot cannot be seen when lighting the unit, the logs have been incorrectly positioned.
- 7. The unit should never be turned off, and on again without a minimum of a 60 second wait.

 Hook up remote receiver to wire marked 'receiver' which will be located on the bottom of the appliance. This remote control requires coding. See remote control instructions for details.

**NOTE:** This appliance will operate during power outages. Only the fan will not operate until power is restored. If the remote batteries in both the handheld transmitter or receiver lose power, the appliance can still be operated by sliding the switch on the receiver switch from "Remote" to "ON". To turn on the appliance off slide the receiver switch from "ON" to "Remote" or "OFF".

**IMPORTANT:** The remote control system supplied with this appliance has several options for starting/operating the appliance, please read the remote control operating instructions (packed with remote control) to understand how to operate this remote system. You can download remote functions video with the QR code below.



Proflame video

# LIGHTING PROCEDURE

# IMPORTANT Prior to igniting or re igniting the pilot, remove the glass door.

Important: If the pilot does not hold, turn pilot knob to "OFF" position. Wait 5 minutes to clear gas. If you smell gas - STOP! Follow the safety information above. If you don't smell gas, repeat Steps 1-6.

- 1. Push in gas control knob slightly and turn to "PILOT" position.
- Push in control knob all the way and hold in until the pilot lights up. Continue to hold the control knob in for about 20 seconds after the pilot is lit. Release knob.
- Push in gas control knob slightly and turn to "ON" position.
- 4. Ensure the receiver is in the remote position.

Set Switch to



Diagram 1


Press and release the ON/OFF button on the remote handheld transmitter. An audible beep should be heard from the receiver.



Diagram 2

Remote shown in Manual Mode on Hi

Note: May not be exactly as shown as hand-held may be silver or black.



6. The unit will turn on.

# SHUTDOWN PROCEDURE

- 1. Press "OFF" on the remote or slide receiver switch from remote to "OFF".
- 2. Turn the gas control knob to the "OFF" position to turn off the pilot.

Pilot may be shut off during prolonged nonuse periods to conserve fuel.

# operating instructions

## **COPY OF THE LIGHTING PLATE INSTRUCTIONS**

# FOR YOUR SAFETY READ BEFORE LIGHTING POUR VOTRE SÉCURITÉ - À LIRE AVANT LA MISE EN MARCHE

WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life. Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with this appliance. For assistance or additional information consult a qualified installer, service agency or gas supplier.

AVERTISSEMENT. Quiconque ne respecte pas à la lettre les instructions dans la présente notice risquede déclencher un incendie ou une explosion entraînant des dommages, des blessures ou la mort. Une installation, d'ajustement, de modification, de service ou d'entretien peut provoquer des blessures ou des dommages matériels. Reportez-vous au manuel du propriétaire fourni avec cet appareil. Pour obtenir de l'aide ou des informa-

tions supplémentaires consulter un installateur qualifié, une agence de service ou fournisseur de gaz.

A) This appliance has a pilot that must be lighted by hand. When lighting the pilot, follow these instructions exactly.
 BEFORE LIGHTING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
 WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
  Do not try to light any appliance.
  Do not touch any electric switch, do not use any phone in your building
- Leave the building immediately.

  Immediately call your gas supplier from a neighbours phone. Follow the gas supplier's instructions If you cannot reach your gas supplier, call the fire department.
- C) Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, do not try to repair it; call a qualified service technician. Force or attempted repair may result in a fire or explosion.
   D) Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and replace

- any part of the control system and any gas control which has been underwater.

  A) Cet appareil est muni d'une veilleuse qui doit être allumée manuellement. Respectez les instructions ci-dessous à la lettre.

  B) AVANT LA MISE EN MARCHE, reniflez tout autour de l'appareil pour déceler une odeur de gaz. Reniflez au niveau du plancher, car certains gaz sont plus lourds que l'air et peuvent s'accumuler au niveau du sol

### QUE FAIRE SI VOUS SENTEZ UNE ODEUR DE GAZ :

- Ne tentez pas d'allumer l'appareil Ne touchez à aucun interrupteur; n'utilisez pas de téléphones se trouvant dans le bâtiment.
- Sortez du bâtiment immediatement

- Appelez immédiatement votre fournisseur de gaz depuis un téléphone extérieur. Suivez les instructions du fournisseur.
  Si vous ne pouvez pas rejoindre le fournisseur, appelez le service incendie.
  C) Ne poussez ni ne tournez la manette d'admission du gaz qu'à la main. Ne jamais employer d'outil à cette fin. Si la manette reste coincée, ne tentez pas de la réparer; appelez un technicien qualifié. Quiconque tente de forcer la manette ou de la réparer peut provoquer une explosion ou ur incendie.
- D) N'utilisez pas cet appareil s'il a été plongé dans l'eau, même partiellement. Faites inspecter l'appareil par un technicien qualifié et remplacez tout élément du système de contrôle ou de commande qui a été plongé dans l'eau.

CAUTION: Hot while in operation. Do not touch. Severe burns may result. Due to high surface temperatures keep children, clothing and furniture, gasoline and other liquids having flammable vapors away. Keep burner and control compartment clean. See installation and operating instructions accompanying appliance.

ATTENTION: Surfaces chaudes lorsque l'appareil est en marche. Ne pas toucher. Risque de brûlures graves. En raison des températures élevées, les enfants, les vêtements et le mobilier, le carburant et tout autre liquide aux vapeurs inflammables doivent être tenus éloignés de l'appareil. Nettoyer régulièrement le brûleur et le compartiment des commandes. Voir les consignes d'installation et d'utilisation fournies avec l'appareil.

# LIGHTING INSTRUCTIONS / CONSIGNES D'ALLUMAGE

- 1) STOP! Read the safety information above on this label.
- 2) Push in gas control knob slightly and turn clockwise / to "OFF". Knob cannot be turned from "PILOT" to "OFF" unless knob is pushed in





- 3) Wait five (5) minutes to clear out any gas. If you then smell gas STOP! Follow step "B" in the Safety Information above on this label. If you don't smell gas, go to the next step.
- 4) Push in gas control knob slightly and turn counterclockwise to "PILOT" position.
- 5) Push in control knob all the way and hold in until the pilot lights. Continue to hold the control knob in for about 20 seconds after the pilot lights.
- to "ON" position 6) Push in gas control knob slightly and turn counterclockwise
- 7) Turn on the flame switch.

## 1) STOP! Lire les instructions de sécurité sur la portion supérieure de cette étiquette.

- en position OFF. Le bouton ne peut pas être tourné 2) Enfoncer légèrement le bouton de commande de gaz et tournez dans le sens horaire  $\diagup$ du PILOT à OFF à moins que le bouton soit enfoncé légèrement. Ne forcez pas
- 3) Attendre cinq (5) minutes pour laisser échapper tout le gaz. Si vous sentez une odeur de gaz, ARRÊTEZ! Passez à l'étape "B" des instructions de sécurité sur la portion supérieure de cette étiquette. S'il n'y a pas d'odeur de gaz, passez à l'étape suivante.

  4) Enfoncer légèrement le bouton de commande de gaz et tournez dans le sens antihoraire 

  en position PILOT.
- 5) Pousser le bouton de commande de gaz à fond et le maintenir enfoncé jusqu'à ce que la veilleuse s'allume. Maintenir le bouton de commande de gaz enfoncé pendant environ 20 secondes après l'allumage de la veilleuse. Relâcher le bouton de commande de gaz.
- 6) Enfoncer légèrement le bouton de commande de gaz et tourner dans le sens antihoraire 🗡

# TO TURN OFF GAS TO APPLIANCE / POUR COUPER LE GAZ AU NIVEAU DE L'APPAREIL

- 1) Turn off the flame switch
- 2) Push in the gas control knob slightly and turn clockwise to "OFF". Do not force.
- 3) Turn off all electric power to the appliance if service is to be performed.
  - You may shut off the pilot during prolonged non use periods to conserve fuel.
- 1) Fermer l'interrupteur de flamme.
- 2) Enfoncer légèrement le bouton de commande de gaz et tournez dans le sens horaire en position OFF. Ne pas forcer.
- 3) Avant d'effectuer des opérations d'entretien, couper l'alimentation électrique de l'appareil.

Pour économiser le carburant, vous pouvez éteindre la veilleuse lorsque l'appareil reste longtemps inutilisé.

DO NOT REMOVE THIS INSTRUCTION PLATE

NE PAS ENLEVER CETTE ÉTIQUETTE D'INSTRUCTIONS

# NORMAL OPERATING SOUNDS OF GAS APPLIANCES

It is possible that you will hear some sounds from your gas appliance. This is perfectly normal due to the fact that there are various gauges and types of steel used within your appliance. Listed below are some examples. All are **normal operating sounds** and should not be considered as defects in your appliance.

## **Blower:**

Regency® gas appliances use high-tech blowers to push heated air farther into the room. It is not unusual for the fan to make a "whirring" sound when ON. This sound will increase or decrease in volume depending on the speed setting of your fan speed control.

## **Burner Tray:**

The burner tray is positioned directly under the burner tube(s) and logs and is made of a different gauge material from the rest of the firebox and body. Therefore, the varying thicknesses of steel will expand and contract at slightly different rates which can cause "ticking" and "cracking" sounds. You should also be aware that as there are temperature changes within the unit these sounds will likely reoccur. Again, this is normal for steel fireboxes.

## **Blower Thermodisc:**

When this thermally activated switch turns ON it will create a small "clicking" sound. This is the switch contacts closing and is normal.

## **Pilot Flame:**

While the pilot flame is on it can make a very slight "whisper" sound.

# **Gas Control Valve:**

As the gas control valve turns ON and OFF, a dull clicking sound may be audible, this is normal operation of a gas regulator or valve.

## Unit Body/Firebox:

Different types and thicknesses of steel will expand and contract at different rates resulting in some "cracking" and "ticking" sounds will be heard throughout the cycling process.

# THERMOPILE / THERMOCOUPLE

- 1. Loosen the thermocouple or thermopile with a 7/16" wrench at bracket.
- Disconnect thermocouple by loosening nut from the valve with a 9 mm wrench. Disconnect thermopile by loosening 2 screws marked TP on the valve.
- 3. Drop the thermocouple or thermopile down from the bracket and pull it out of the unit.
- 4. Reinstall the new ones in reverse order.

# **MAINTENANCE INSTRUCTIONS**

- Always turn off the gas valve before cleaning. For relighting, refer to lighting instructions. Keep the burner and control compartment clean by brushing and vacuuming at least once a year. When cleaning the logs, use a soft clean paint brush as the logs are fragile and easily damaged.
- Clean appliance and door with a damp cloth (never when the unit is hot). Never use an abrasive cleaner.

The heater is finished in a heat-resistant paint and should only be refinished with heat-resistant paint. Regency® uses Stove Brite Paint - Metallic Black #6309.

- 3. The glass should be cleaned with a gas fireplace glass cleaner when it starts to turn milky.
- 4. Make a periodic check of burner for proper position and condition. Visually check the flame of the burner periodically, making sure the flames are steady; not lifting or floating. If there is a problem, call a qualified service person.
- The appliance and venting system must be inspected before use, and at least annually, by a qualified field service person, to ensure that the flow of combustion and ventilation air is not obstructed.
  - During the annual service call, the burners should be removed from the burner tray and cleaned. Replace the embers and rock wool.
- Keep the area near the appliance clear and free from combustible materials, gasoline and other flammable vapours and liquids.

# **CAUTION:**

ANY SAFETY SCREEN OR GUARD REMOVED FOR SERVICING AN APPLIANCE MUST BE REPLACED PRIOR TO OPERATING THE APPLIANCE.

NEVER OPERATE THE APPLIANCE WITHOUT THE GLASS PROPERLY SECURED IN PLACE.

# GENERAL VENT MAINTENANCE

Conduct an inspection of the venting system semiannually. Recommended areas to inspect are:

- Check areas of the Venting System which are exposed to the elements, for corrosion. These will appear as rust spots or streaks, and in extreme cases, holes. These components should be replaced immediately.
- Remove the Cap, and shine a flashlight down the Vent. Remove any birds nests, or other foreign material.
- Check for evidence of excessive condensation, such as water droplets forming in the inner liner, and subsequently dripping out the joints. Continuous condensation can cause corrosion of caps, pipe, and fittings. It may be caused by having excessive lateral runs, too many elbows, and exterior portions of the system being exposed to cold weather.
- Inspect joints, to verify that no pipe sections or fittings have been disturbed, and consequently loosened. Also check mechanical supports such as Wall Straps for rigidity.

# **LOG REPLACEMENT**

The unit should never be used with broken logs. Turn off the gas valve and allow the unit to cool before opening door to carefully remove the logs. The pilot light generates enough heat to burn someone. If for any reason a log should need replacement, use only Regency® replacement logs. The position of these logs must be as shown in the Diagram under Log Installation.

Note: Improper positioning of logs may create carbon buildup and will alter the unit's performance which is not covered under warranty.

# 48 maintenance


# **GLASS GASKET**

If the glass gasket requires replacement use (Part # 846-684).

# GLASS REPLACEMENT

Your CLASSIC stove is supplied with high temperature, 5 mm Neoceram ceramic glass that will withstand the highest heat that your unit will produce. In the event that you break your glass by impact, purchase your replacement glass from an authorized Regency® dealer only.

If the front glass requires replacement, use part # 490-548.



# REMOVING VALVE ASSEMBLY

- 1. Shut off gas and electrical supply.
- If optional fan is installed, disconnect power source to stove.
- 3. Remove access panel.
  - **a)** Front panel on pedestal model. See Diagram 1.
  - **b)** Panel from bottom of leg shield. See Diagram 2.

# Note: Access panel only has to be loosened to be taken out.

- Remove valve cover plate by removing two (2) screws.
- 5. Disconnect receiver wire.
- 6. Remove cover plate by removing 4 screws (Pedestal option only).
- 7. Disconnect gas line to stove.




Diagram 1




Diagram 2

- 8. Disconnect 3/8" NPT pipe from 90° elbow on valve.
- 9. Disconnect the two (2) switch wires from valve.
- 10. Disconnect three (3) fan wire from DC sparker.
- 11. Remove orifice.
- Loosen four (4) Phillips head M5 valve mounting screws from underside of firebox. Drop valve assembly down.

To remove valve from valve assembly, continue.

- 13. Remove two (2) thermopile wires.
- Remove thermocouple with a 9 mm (metric) wrench.
- 15. Remove pilot nut with an 11 mm wrench.
- Remove valve to orifice nut with a 13/16" wrench.
- 17. Remove inlet pipe with pipe wrench. Note orientation of 90o elbow.
- 18. Remove two (2) phillips head M5 screws on each side of the valve.
- 19. Remove valve and remove gas out 900 brass fitting. Note orientation of fitting.

See Diagram in "Optional Fan Installation" section for more detail.

# INSTALLING VALVE ASSEMBLY

- To install a new valve assembly, reverse instructions for removing valve. See assembly steps 1-10.
- Check for leaks and manifold pressure. See Gas Pressure Test instructions.
- To reinstall valve, reverse instructions for removing valve assembly, steps 11-17.

# **GAS MAINTENANCE - RECOMMENDED ANNUAL ROUTINE**

In order for your Regency appliance to continue to provide comfort to your home periodic maintenance must be performed to ensure it is operating at peak efficiency. The items in the list should be checked by a licensed gas service technician during the annual service check. Your unit may require more frequent maintenance checks if you notice any changes in how it operates. Operational changes to look for can include, but are not limited to, extended start up time, increased fan noise, residue/carbon build up, white build up on the glass/firebox, increased operating noise etc. Should any of these or other conditions arise, discontinue use and schedule a service check with your local licensed gas technician. The list below shows items your licensed service technician will need to check and service at least annually.

# Clean

- Glass
- Interior bricks / panels
- · Burner ports & burner air shutter
- Fan blades
- Log set
- Pilot orifices
- Pilot hood (change as needed)
- Flame sensor (electronic ignition models)
- Flame electrode
- Burner orifice
- Thermocouple (millivolt models)
- Thermopile (millivolt models)

# Gas Leak Tests

- · Check main gas line connection to valve
- Check shut off valve connections
- · Check connection at gas valve outlet
- · Check connection at main burner orifice
- Check pilot fuel line at valve and at pilot assembly

# Inspect

- Pilot assembly
- Burner
- · Pressure relief gaskets/doors
- Flue connector gasket if present
- Door seal
- Firebox
- Venting
- Batteries (remote handheld, remote receiver, DC sparker, change as needed)
- Burner media (change as needed)
- Air shutter setting
- Wiring

# Check

- Voltage on thermocouple/thermopile (millivolt models)
- Ohms reading on flame sense (electronic ignition models)
- Inlet/outlet fuel pressures as per rating plate
- Voltage/ohms readings on gas valve
- Ohms reading to on/off switch circuit (Milivolt models)


# parts list 50

# **MAIN ASSEMBLY**

	Part #	Description
1. 2.	493-005 494-941 494-943	Safety Screen Small Door - Black Small Door - Nickel Accent
3. 4. 5. 6. 7.	490-548 846-684 494-754 490-028 490-030	Small Glass (includes Glass Gasket) 1/8" x 1" Wide Window/Glass Gasket Tape (6') (936-240) Door Handle Assembly Glass Frame Door Handle
12.	846-699	Door Gasket 3/4" Rope (5') (936-233)
14. 17. 19.	* 471-031 948-146	Screw 10-24 x 3/4"  Door Retainer Clip  Wood Handle
20 21. 22.	493-917 910-157/P 910-142 910-813	Complete Fan Assembly (Optional) Blower Motor (120V) Fan Auto on/off Thermodisc Power Cord (120V)  28 26 37
24. 25. 26. 27. 28. 30 31. 32. 33. 35. 37. 38. 40 41.	* * * 936-197 936-194 W260260 942-117 W260280 290-021 * * 490-081 490-520 490-042 920-092	Gasket - Air Passage Flex Pipe - 3" ID Stainless Steel Hose Clamp Gasket - Flue Collar/Starter Collar Gasket - Starter Collar/Air Passage Relief Frame Gasket Top Relief Plate Frame Top Relief Plate Gasket Air Baffle Plate Capscrew 1/4 x 1-3/4" NC Upper Air Passage Assembly Flue Restrictor Top Assembly Rear Panel  Manual  replacement part.  35  26  31  32  33  34  35  36  37  38  38  38  38  38  38  38  38  38
NOC	avaliable as a	12 12 22 20 19 19 22 20 19 19 19 19 19 19 19 19 19 19 19 19 19

# **BURNER ASSEMBLY & LOG SET**

## Part # Description




# parts list 52

# **BASE OPTIONS**


	Part #	Description		Part #	Description
	494-921	Complete Floor Shield		494-926	Pedestal Assembly
100	948-223	Regency® Logo	100	948-223	Regency® Logo
102.	904-257	Magnetic Catch (Large)	102.	904-257	Magnetic Catch (Large)
103.	*	11" Pedestal Hinge	103.	*	11" Pedestal Hinge
110	910-327	Strain Relief for Power Cord	110	910-327	Strain Relief for Power Cord
121.	490-005	Access Panel	123.	490-070	Pedestal Blanking Plate
			124.	820-058	Pedestal Cover Plate
140.	850-126	Cast Legs - Black (4/set)	125.	490-002	Rear Cover Plate
	850-128	Cast Legs - Brush Nickel (4/set)			

<sup>\*</sup>Not available as a replacement part.



FLOOR SHIELD (OPTIONAL)

PEDESTAL (OPTIONAL)



LEGS (OPTIONAL)

notes

53

# 54 warranty

# **Limited Lifetime Warranty**

FPI Fireplace Products International Ltd. (for Canadian customers) and Fireplace Products US, Inc. (for US customers) (collectively referred to herein as "FPI") extends this Limited Lifetime Warranty to the original purchaser of this Appliance provided the product remains in the original place of installation. The items covered by this Limited Lifetime Warranty and the period of such coverage are set forth in the table below.

An Appliance in this policy is defined as an Indoor Gas Fireplace, Indoor Gas Insert, Indoor Gas Freestanding Stove.

## This Appliance has only been certified and listed for use indoors.\*\*

This Limited Lifetime Warranty starts on the day the Appliance was purchased.

\*\*Note: There are select models which are approved for both indoor/outdoor use. See specific product manuals for details.

The Limited Lifetime Warranty is not transferable, amendable or negotiable under any circumstances.

Indoor Gas Products	Limited				Subsidized Labor Coverage*
Warranty Coverage Parts and Labor	Lifetime	5 years	2 years	1 year	(Years)
Firebox and Heat Exchanger	✓				3
Steel Burner Tube	✓				3
Glass Thermal breakage only	✓				3
All painted Surrounds/Inlays Finishes White/Black Chase Vents/Steel Framing Kits		<b>√</b>			3
Brick Panels/Log sets/Ceramic Burners/Grates		✓			3
All Castings		<b>✓</b>			3
Valve assembly and all gas control components (Pilot assembly, flame sensors, Spark Electrode, Pilot Tubing, Orifices, Thermocouple, Thermopile)			<b>✓</b>		2
All Other Electrical components (Ignition Control Boards, Wiring, Wiring Harnesses, Lighting Wiring Assemblies, Switches, Blowers, Blower Control Module, Battery Pack, Remote Control Systems)			<		2
Enamel Panels/Painted Steel Panels			✓		1
Venting/Venting Components			✓		1
All Stainless steel surrounds All black chrome Brushed nickel/Antique copper Faceplates/surrounds All Inner/Outer Black Glass panels				<b>√</b>	1
All Firebox Media (Glass Crystals, Crushed Glass,					
Glass Fire beads, Volcanic, Ceramic, Spa Stones,				✓	1
River Pebbles, Fireballs)					
All hardware				✓	1
WIFI Dongle				✓	1
Mesh/Glass Safety Barriers				✓	1
Accent Light Bulbs				✓	1
Glass (Crazing)				✓	1

Note: Warranty coverage noted above may not be applicable as components/options vary based on appliance purchased.

# **Conditions:**

Warranty protects against defect in manufacture or FPI factory-assembled components only, unless herein specified otherwise.

\*This warranty does not cover dealer travel costs, mileage, fuel, tolls for diagnostic or service work. All labor rates paid to authorized dealers are subsidized, pre-determined rates. Dealers may charge you for travel and additional time beyond their subsidy.

Any part(s) found to be defective during the warranty period as outlined above will be repaired or replaced at FPI's option through an accredited distributor, dealer or pre-approved and assigned agent; provided that the defective part is returned to the distributor, dealer or agent for

inspection if requested by FPI. Alternatively, FPI may, at its discretion, fully discharge all of its obligations under warranty by refunding the verified purchase price of the product to the original purchaser. The purchase price must be confirmed by the original Bill of Sale. The authorized selling dealer, or an alternative authorized FPI dealer if pre-approved by FPI, is responsible for all in-field diagnosis and service work related to all warranty claims. FPI is not responsible for results or costs of workmanship of unauthorized FPI dealers or agents in the negligence of their service work.

At all times, FPI reserves the right to inspect reported in the field/on location complaints of products claimed to be defective before processing or authorizing any claim. Failure to allow this upon request will void the warranty.

All warranty claims must be submitted by the dealer servicing the claim, including a copy of the Bill of Sale (proof of purchase by you). All claims must be complete and provide full details as requested by FPI to receive consideration for evaluation. **Incomplete claims may be rejected.** 

Replacement Appliances to the original purchaser are limited to one per warranty term. Appliances must be installed according to all manufacturers' instructions as per the manual. All Local and National required codes must be met.

The installer is responsible for ensuring the Appliance is operating as designed at the time of installation.

The original purchaser is responsible for the annual maintenance of the Appliance, as outlined in the owner's manual. As outlined below, the warranty may be voided due to problems caused by a lack of maintenance.

Records/receipts of any maintenance completed on the appliance must be kept in case asked for when dealer submits a warranty claim.

Purchased parts: Repair/replacement parts purchased by the consumer from FPI after the original coverage has expired on the Appliance will carry a **90-day** warranty from the purchase date, valid with a receipt only. Any item shown to be defective will be repaired or replaced at our discretion. No labor coverage is included with these parts.

Special Finishes - One year on brushed nickel, black chrome and antique copper faceplates/surrounds. You can expect some changes in color as the product "ages" with constant heating and cooling. FPI warranties the product for any manufacturing defects on the original product. However, the manufacturer's warranty does not cover changing colors and marks, i.e. fingerprints, etc. applied after the purchase of the product. Damage from the use of abrasive cleaners is not covered by warranty.

If freight damage has been found either externally or internally, the dealer must be informed within 3 days. All claims as a result of damage must be submitted by the dealer servicing the claim, including a copy of the Bill of Sale (proof of purchase). All claims must be complete and provide full details as requested by FPI to receive consideration for evaluation. **Incomplete claims may be rejected.** 

As this is a Limited Lifetime Warranty, if the Appliance needs to be replaced, the Appliance that was purchased at the time of sale might not be replaced with exactly the same model Appliance. In that case, FPI will replace your Appliance with one that is similar at the time of replacement under the terms of this Limited Lifetime Warranty, but ONLY in the event that an item covered by the Limited Lifetime Warranty is found to be defective. Please refer to the table on first page of this warranty for items covered by the Limited Lifetime Warranty. Product changes might be the result of the original Appliance being discontinued, changes in regulatory requirements, product advancements, etc., which are beyond the control of FPI. This Limited Lifetime Warranty does not cover any installation costs, or costs associated with changes of required clearances for the replacement Appliance, hearth pads, mantles, facing and/or facing materials such as framing, completed walls made of drywall, wood, non-combustible board, tile, brick, stone, marble etc., venting/chimney systems, or components of the chimney system.

If a suitable replacement is not available, FPI will refund 50% of the purchase price of the Appliance and any applicable FPI accessories (faceplates, brick panels, media, etc.) purchased at the time of sale. In no event will FPI refund any portion of the purchase price of, or reimburse costs associated with, any other items, including without limitation, installation of a new Appliance, changes of required clearances for a new Appliance, hearth pads, mantles, facing and/or facing materials such as framing, completed walls made of drywall, wood, non- combustible board, tile, brick, stone, marble etc., venting/chimney systems, or components of the chimney system. A copy of the receipt or bill of sale will be necessary to validate the purchase price.

## For appliances approved for both Indoor/Outdoor use:

Optional finishing trims and faceplate's may be used in the outdoor environment. Plated faceplates are not recommended for outdoor installation due to the high potential for oxidation to form on the surface. However, please note that some fading or corrosion will occur due to environmental exposure. This would also apply to the gas appliance. Rust/corrosion is not covered under the terms of the warranty policy.

Fan kits may be installed but are not recommended in areas where there is high humidity. The appliance must be vented the same as if installed indoors. Follow the same guidelines/venting parameters when this is installed outdoors. Horizontal termination caps must not discharge into the same space shared by the front of the appliance. Vertical termination caps are recommended.

Appliances approved for use outdoors must be installed in a weatherproof enclosure while still following all clearance to combustible materials as outlined in the appliance manual.

# 56 warranty

## **Exclusions:**

This Limited Lifetime Warranty does not extend to paint, rust or corrosion of any kind due to a lack of maintenance or improper venting, combustion air provision, corrosive chemicals (i.e. chlorine, salt, air, etc.), door, valve, pilot, fan cover, pressure relief door or glass gasketing, batteries, color fading, carbon/sooting of the log sets due to use and does not cover lava rock, platinum/glowing embers, andiron black embers, vermiculite.

Malfunction, damage or performance-based issues as a result of environmental conditions, location, chemical damages, downdrafts, installation error, an installation by an unqualified installer, incorrect chimney components (including but not limited to cap size or type), operator error, abuse, misuse, use of improper fuels, lack of regular maintenance and upkeep, acts of God, weather-related problems from hurricanes, tornados, earthquakes, floods, lightning strikes/bolts or acts of terrorism or war, which result in a malfunction of the Appliance are not covered under the terms of this Limited Lifetime Warranty.

FPI has no obligation to enhance or modify any Appliance once manufactured (i.e. as products evolve, field modifications or upgrades will not be performed on existing Appliances).

Any Appliance showing signs of neglect or misuse will not be covered under the terms of this warranty policy and may void this warranty, including Appliances with rusted or corroded fireboxes that have not been reported as rusted or corroded within **three (3)** months of installation/purchase.

Appliances which show evidence of being operated while damaged, or with problems known to the purchaser and causing further damages will void this warranty.

Appliances where the serial no. has been altered, deleted, removed or made illegible will void this warranty.

Minor movement, expansion and contraction of the steel is normal and is not covered under the terms of this warranty.

Freight damages for products or parts are not covered under the terms of the warranty.

Products made or provided by other manufacturers and used in conjunction with the FPI Appliance without prior authorization from FPI may void this warranty.

## **Limitations of Liability:**

The original purchaser's exclusive remedy under this warranty, and FPI's sole obligation under this Limited Lifetime Warranty, express or implied, in contract or in tort, shall be limited to replacement, repair, or refund, as outlined above. IN NO EVENT WILL FPI BE LIABLE UNDER THIS WARRANTY FOR ANY INCIDENTAL OR CONSEQUENTIAL COMMERCIAL DAMAGES OR DAMAGES TO PROPERTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, FPI MAKES NO EXPRESS WARRANTIES OTHER THAN THE WARRANTY SPECIFIED HEREIN. THE DURATION OF ANY IMPLIED WARRANTY IS LIMITED TO DURATION OF THE EXPRESSED WARRANTY SPECIFIED ABOVE. IF IMPLIED WARRANTIES CANNOT BE DISCLAIMED, THEN SUCH WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some US states do not allow limitations on how long an implied warranty lasts, or allow exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

 $Customers \, located \, outside \, the \, US \, should \, consult \, their \, local, \, provincial \, or \, national \, legal \, codes \, for \, additional \, terms, \, which \, may \, apply \, to \, this \, warranty.$ 

# **How to Obtain Warranty Service:**

Customers should contact the authorized selling dealer to obtain warranty service. In the event the authorized selling dealer is unable to provide warranty service, please contact FPI by mail at the address listed below. Please include a brief description of the problem and your address, email and telephone contact information. A representative will contact you to make arrangements for an inspection and/or warranty service.

<u>Canadian Warrantor:</u> <u>U.S. Warrantor:</u>

FPI Fireplace Products International Ltd. Fireplace Products US, Inc.

6988 Venture St. Delta, British Columbia

Canada, V4G 1H4

PO Box 2189 PMB 125

Blaine, WA

United States, 98231

Or contact the Regency Customer Care Centre at 1-800-442-7432 (phone) / 604-946-4349 (fax) /customerservice@regency-fire.com (e-mail)

# **Product Registration and Customer Support:**

Thank you for choosing a Regency Fireplace. Regency strives to be a world leader in the design, manufacture, and marketing of hearth products. To provide the best support for your product, we request that you complete a product registration form at <a href="http://www.regency-fire.com/Customer-Care/Warranty-Registration.aspx">http://www.regency-fire.com/Customer-Care/Warranty-Registration.aspx</a> within <a href="mailto:ninety">ninety</a> (90) days of purchase.



## **Product Registration and Customer Support:**

Thank you for choosing a Regency Fireplace. Regency strives to be a world leader in the design, manufacture, and marketing of hearth products. To provide the best support for your product, we request that you complete a product registration form found on our Web Site under Customer Care within ninety (90) days of purchase.

For purchases made in CANADA or the UNITED STATES:

http://www.regency-fire.com/Customer-Care/Warranty-Registration.aspx

For purchases made in AUSTRALIA:

http://www.regency-fire.com.au/Customer-Care/Warranty-Registration.aspx

You may also complete the warranty registration form below to register your Regency Fireplace Product and mail and/or fax it back to us, and we will register the warranty for you. It is important you provide us with all the information below in order for us to serve you better.

## Warranty Registration Form (or Register online immediately at the above Web Site):

Warranty Details				
Serial Number (required):				
Purchase Date (required) (mm/dd/yyyy):				
Product Details				
Product Model (required):				
Dealer Details				
Dealer Name (required):				
Dealer Address:				
Dealer Phone #:				
Installer:				
Date Installed (mm/dd/yyyy):				
Your Contact Details (required)				
Name:				
Address:				
Phone:				
Email:				

For purchases made in CANADA: For purchases made in the UNITED STATES: For purchases made in AUSTRALIA:

**FPI Fireplace Products** Fireplace Products US, Inc. **Fireplace Products Australia Pty Ltd** International Ltd. PO Box 2189 PMB 125 99 Colemans Road 6988 Venture St. Blaine, WA Delta, British Columbia United States, 98231 Canada, V4G 1H4

Dandenong South, Vic. 3175 Australia

Phone: +61 3 9799 7277 Phone: 604-946-5155 Phone: 604-946-5155 Fax: +61 3 9799 7822 Fax: 1-866-393-2806 Fax: 1-866-393-2806

For fireplace care and tips and answers to most common questions please visit our Customer Care section on our Web Site. Please feel free to contact your selling dealer if you have any questions about your Regency product.

# **PRODUCT LIFE CYCLE:**

By recycling your used appliances, you divert waste from your local landfills and help the environment. You also reduce the need for raw materials to manufacture new products. Contact your local municipality for appliance recycling services, local recycling programs, or appliance removal services to ensure your Regency appliance components, and packaging are properly recycled.

Installer: Please complete the following information				
Dealer Name & Address:				
Installer:				
Phone #:				
Date Installed:				
Serial #:				



C34 Video