



# eStudio

LED Electric Fire Range  
with Thermostatic Remote Control



## Instructions for Use, Installation & Servicing

For use in AU & NZ (Australia & New Zealand)

### IMPORTANT

PARTS OF THE OUTER CASING OF THIS APPLIANCE ARE CONSIDERED BY THE MANUFACTURER TO BE A WORKING SURFACE WHICH BECOMES HOT WHEN THE HEATER IS IN OPERATION AND WILL RESULT IN SERIOUS INJURY AND BURNS IF TOUCHED. IT IS THEREFORE RECOMMENDED THAT A FIREGUARD IS USED IN THE PRESENCE OF YOUNG CHILDREN, THE ELDERLY OR INFIRM.

THE HEATER OUTLET GRILLE BECOMES VERY HOT WHILST IN OPERATION.  
DO NOT COVER THE OUTLET GRILLE OR ANY PART OF THE APPLIANCE.

For use with 230V 50Hz electricity supply only.

Please read these instructions carefully before installation and keep them in a safe place.




They will be needed when maintenance or servicing is required.

**THIS APPLIANCE MUST BE EARTHED**

**THIS PRODUCT IS ONLY SUITABLE FOR WELL INSULATED SPACES AND OCCASIONAL USE.**

## TECHNICAL SPECIFICATION



eSTUDIO 60R	eSTUDIO 85R	eSTUDIO 105R	eSTUDIO 135R	eSTUDIO 165R
223-403	223-417	223-439	223-465	223-476



	A	B	C	D	E	F	G	H	I	J	K	L
<b>eStudio 60R</b>	600	600	628	688	628	112	614	38	764	204	614	225
<b>eStudio 85R</b>	836	330	864	924	358	112	344	38	494	175	850	196
<b>eStudio 105R</b>	1036	330	1064	1124	358	112	344	38	494	175	1050	196
<b>eStudio 135R</b>	1336	330	1364	1424	358	112	344	38	494	175	1350	196
<b>eStudio 165R</b>	1574	330	1602	1662	358	112	344	38	494	175	1588	196


## INSTALLATION INSTRUCTIONS

### CAVITY CONSTRUCTION



	A	B	C
eStudio 60R	705	790	223
eStudio 85R	941	520	193
eStudio 105R	1141	520	193
eStudio 135R	1441	520	193
eStudio 165R	1679	520	193

### PRE-INSTALLATION



INSTALLATION INSTRUCTIONS

INSTALLATION

